




Part 650 Engineering Field Handbook National Engineering Handbook

Chapter 14 Water Management (Drainage)



Issued February 2021

In accordance with Federal civil rights law and U.S. Department of Agriculture (USDA) civil rights regulations and policies, the USDA, its Agencies, offices, and employees, and institutions participating in or administering USDA programs are prohibited from discriminating based on race, color, national origin, religion, sex, gender identity (including gender expression), sexual orientation, disability, age, marital status, family/parental status, income derived from a public assistance program, political beliefs, or reprisal or retaliation for prior civil rights activity, in any program or activity conducted or funded by USDA (not all bases apply to all programs). Remedies and complaint filing deadlines vary by program or incident.

Persons with disabilities who require alternative means of communication for program information (e.g., Braille, large print, audiotope, American Sign Language, etc.) should contact the responsible Agency or USDA's TARGET Center at (202) 720-2600 (voice and TTY) or contact USDA through the Federal Relay Service at (800) 877-8339. Additionally, program information may be made available in languages other than English.

To file a program discrimination complaint, complete the USDA Program Discrimination Complaint Form, AD-3027, found online at [How to File a Program Discrimination Complaint](#) and at any USDA office or write a letter addressed to USDA and provide in the letter all of the information requested in the form. To request a copy of the complaint form, call (866) 632-9992. Submit your completed form or letter to USDA by: (1) mail: U.S. Department of Agriculture, Office of the Assistant Secretary for Civil Rights, 1400 Independence Avenue, SW, Washington, D.C. 20250-9410; (2) fax: (202) 690-7442; or (3) email: program.intake@usda.gov.

USDA is an equal opportunity provider, employer, and lender.

Table of Contents

650.1400	Introduction	14.1
650.1401	Types of Drainage Systems	14.8
650.1402	Investigations and Planning	14.9
650.1403	Surface Drainage	14.17
650.1404	Investigation and Planning of Surface Drainage Systems	14.19
650.1405	Design of Open Drains	14.25
650.1406	Construction	14.42
650.1407	Maintenance	14.44
650.1408	Subsurface Drainage	14.47
650.1409	Applications of Subsurface Drainage	14.51
650.1410	Investigations and Planning	14.55
650.1411	Field Drainage System Design	14.58
650.1412	Drain Envelopes	14.78
650.1413	Materials	14.86
650.1414	Appurtenances	14.90
650.1415	Drain Installation	14.94
650.1416	Maintenance	14.101
650.1417	Interception Drainage Design	14.103
650.1418	Water Table Management	14.110
650.1419	Controlled Drainage	14.112
650.1420	Subirrigation	14.114
650.1421	Drainage Pumping	14.120
650.1422	Definitions of Terms	14.125
650.1423	References	14.143
650.1424	Acknowledgement	14.146
Appendix 14A	Ditch Design Tables	14A.1
Appendix 14B	Tables for Computing Culvert Discharge	14B.1
Appendix 14C	Salinity Monitoring Equipment	14C.1
Appendix 14D	Auger-hole Procedure for Hydraulic Conductivity	14D.1
Appendix 14E	Transient Flow Method	14E.1
Appendix 14F	Drainage Around Home Sites	14F.1

Table of Figures

Figure 14-1: Cropland in Need of Drainage Maintenance	14.1
Figure 14-2: Field Drainage System in Need of Maintenance	14.2
Figure 14-3: Extent of Subsurface Drainage for a Field as Shown by Infrared Photo and Interpretive Sketch	14.12
Figure 14-4: Drainage Curves	14.18
Figure 14-5: Area Application of Drainage Curves	14.18
Figure 14-6: Random Drains	14.21
Figure 14-7: Parallel Surface Drains	14.21
Figure 14-8: Reconstructing Cross Slope Drain System	14.22
Figure 14-9: Surface Drainage Bedding	14.23
Figure 14-10: Earthmoving Scraper with Laser Grade Control	14.24
Figure 14-11: Landplane	14.25
Figure 14-12: Example Computation of Design Flows	14.27
Figure 14-13: Establishing Hydraulic Gradeline	14.28
Figure 14-14: Steepest Side Slopes Recommended for Ordinary Conditions for Mains or Laterals	14.30
Figure 14-15: Ditch Side Slopes Recommended for Maintenance	14.31
Figure 14-16: Permissible Bare Earth Velocities	14.31
Figure 14-17: Value of Manning's n for Drainage Ditch Design	14.32
Figure 14-18: Recommended Minimum Berm Widths	14.33
Figure 14-19: Surface Water Inlets	14.35
Figure 14-20: Watergate	14.36
Figure 14-21: Watershed Sketch	14.38
Figure 14-22: Profile Ditch with Hydraulic Gradient	14.39
Figure 14-23: Open Drain Design Worksheet	14.40
Figure 14-24: Design Profile	14.41
Figure 14-25: Main Drain with Spoil Banks Spread	14.43
Figure 14-26: Seeding Newly Constructed Drain	14.43
Figure 14-27: Maintenance by Mowing	14.45
Figure 14-28: Application of Chemicals for Side Slope Weed Control	14.46
Figure 14-29: Land Leveler Operation for Land Smoothing Maintenance	14.46
Figure 14-30: Land Smoothing Equipment	14.47
Figure 14-31: Subsurface Drain Plan	14.48
Figure 14-32: Subsurface Drain Plan and Layout	14.49

Figure 14-33: Monitoring Salinity Level of Soil-Moisture.....	14.54
Figure 14-34: Estimating Soil Hydraulic Conductivity Using Soil Interpretation Record.....	14.55
Figure 14-35: Soil Profile with Calculations of Hydraulic Conductivity Using Soil Interpretation Record.....	14.56
Figure 14-36: Field Drainage Systems	14.59
Figure 14-37: Drainage Coefficients	14.60
Figure 14-38: Curves to Determine Drainage Coefficient, q , for Arid Areas	14.62
Figure 14-39: Nomenclature Used in Ellipse Equation	14.65
Figure 14-40: Graphical Solution of Ellipse Equation.....	14.67
Figure 14-41: Maximum Trench Depths for Corrugated Plastic Pipe Buried in Loose, Fine-Textured Soils (feet)	14.70
Figure 14-42: Subsurface Drain Discharge.....	14.72
Figure 14-43: Determining Size of Corrugated Plastic Pipe.....	14.73
Figure 14-44: Determining Size of Clay or Concrete Drain Tile ($n = 0.013$)	14.74
Figure 14-45: Values of Manning's n for Subsurface Drains and Conduits	14.75
Figure 14-46: Subsurface Drainage System	14.75
Figure 14-47: Curves to Determine Discharge, Q_r , for Main Drain.....	14.77
Figure 14-48: Filter Envelope Recommendation Relative to Soil Texture (source USDA)...	14.79
Figure 14-49: Typical Bedding or Envelope Installations	14.80
Figure 14-50: Relationships Used to Obtain Fabric Opening Size to Protect Against Excessive Loss of Fines During Filtration (source: Giuard 1982)	14.84
Figure 14-51: Recommendation of Group Classes for Prewrapped Loose Materials	14.85
Figure 14-52: Minimum Filter Envelope Thicknesses.....	14.85
Figure 14-53: Junction Box and Silt Trap	14.91
Figure 14-54: Blind Surface Inlet.....	14.91
Figure 14-55: Vents or Relief Wells.....	14.92
Figure 14-56: Pipe Outlet.....	14.93
Figure 14-57: Outlet Pipe Protection.....	14.93
Figure 14-58: Laser Grade Control.....	14.94
Figure 14-59: Drain Crossings and Outlets	14.95
Figure 14-60: Dimensions for a 90 Degree V Groove for Corrugated Plastic Pipe	14.97
Figure 14-61: High Pressure Jet Cleaning	14.102
Figure 14-62: Ground Water Movement	14.103
Figure 14-63: Typical Interceptor Installations	14.106
Figure 14-64: Diversion System on Moderate to Steep Slopes.....	14.107

Figure 14-65: Interceptor Drain on Bottom Land.....	14.107
Figure 14-66: Interception Drain Inflow Rates.....	14.109
Figure 14-67: Water Table Management Alternatives.....	14.111
Figure 14-68: Water Control Structures	14.113
Figure 14-69: Field Layout of WTM System	14.115
Figure 14-70: Field Layout of Hydraulic Conductivity Tests (1 per 10 acres)	14.116
Figure 14-71: Field Layout of Hydraulic Conductivity Test (Variable Concentration Based on Complexity).....	14.117
Figure 14-72: Range of Conductivity Groups	14.118
Figure 14-73: Subirrigation Lateral Spacing and Water Table Position	14.119
Figure 14-74: Capillary Upward Flux as Demonstrated on the Ditch Side Slope.....	14.120
Figure 14-75: Pump Installation.....	14.121
Figure 14B-1: Values of $a2gh$ for circular pipes flowing full.....	14B.1
Figure 14B-2: Concrete pipe, square cornered entrance.....	14B.1
Figure 14B-3: Concrete pipe – beveled lip.....	14B.2
Figure 14B-4: Concrete pipe, square cornered entrance.....	14B.2
Figure 14B-5: Pipe size vs. area.....	14B.2
Figure 14B-6: Minimum surcharge (h_1) for corrugated metal pipe (ft).....	14B.3
Figure 14B-7: Minimum surcharge (h_1) for concrete pipe (ft).....	14B.3
Figure 14C-1: Mobile Four-Electrode Sensing System.....	14C.1
Figure 14C-2: Combination, Mobile Electromagnetic-Induction/Four-Electrode Sensing System	14C.2
Figure 14D-1: Symbols for Auger-hole Method of Measuring Hydraulic Conductivity.....	14D.1
Figure 14D-2a: Auger-hole Method of Measuring Hydraulic Conductivity—sheet 1 of 2...	14D.4
Figure 14D-2b: Auger-hole Method of Measuring Hydraulic Conductivity—sheet 1 of 2 ..	14D.6
Figure 14D-3: Hydraulic Conductivity—Auger-hole Method Using the Ernst Formula.....	14D.8
Figure 14D-4: Equipment for Auger-hole Method of Measuring Hydraulic Conductivity.	14D.10
Figure 14E-1: Comparison between Computed and Measured Drain Spacings	14E.2
Figure 14E-2: Curves Showing Relationship of Parameters Needed for Drain Spacing Calculations Using the Transient-Flow Theory.....	14E.3
Figure 14E-3: Curve Showing General Relationship between Specific Yield and Hydraulic Conductivity	14E.4
Figure 14E-4: Curves for Determining Hooghoudt's Convergence Correction	14E.7
Figure 14E-5: Expanded Curves for Determining Hooghoudt's Convergence Correction....	14E.7
Figure 14E-6: Approximate Deep Percolation from Surface Irrigation (Percent of Net Input)	14E.8

Figure 14E-7: Curve for Estimating Infiltrated Rainfall.....	14E.10
Figure 14E-8: Approximate Snowmelt and Irrigation Application Dates.....	14E.11
Figure 14E-9: Computation of Water Table Fluctuation with Drain on the Barrier Layer ..	14E.13
Figure 14E-10: Computation of Water Table Fluctuation with Drain on the Barrier Layer Using D' as Corrected by Hooghoudt	14E.14
Figure 14E-11: Water Table Fluctuation.....	14E.15
Figure 14E-12: Computation of Water Table Fluctuation with DRAIN on the Barrier Layer	14E.16
Figure 14F-1: Selection of Building Sites	14F.2
Figure 14F-2: Subsurface Drains Can be Installed Around a Home to Remove Excess Water	14F.3
Figure 14F-3: Correctly installed gutters and downspouts prevent roof water from forming wet or damp conditions around foundation or basement walls	14F.6
Figure 14F-4: Roof water can be routed away from the foundation or basement walls to a storm water drain or another outlet using non-perforated pipe.....	14F.6
Figure 14F-5: Foundation Drain Application	14F.6

Part 650 – Engineering Field Handbook

Chapter 14 – Water Management (Drainage)

650.1400 Introduction

A. Water management is involved in many aspects of natural resource conservation. It is a broad term used to describe application of water for irrigation, control of excess ponded, and the control of excessive soil moisture. The latter is normally called drainage. Most crops and vegetative material require some drainage to provide a favorable environment in the root zone for growth.

B. An important distinction must be made between improving drainage of agricultural producing land and converting wetlands. Present agricultural trends are toward intensive use of existing cropland, with much of the emphasis on new management technologies. Maintaining and improving existing drainage and associated yields on wet agricultural soils presently in production minimizes the economic need for landowners to convert wetlands. This encourages a new emphasis on protecting existing wetlands and establishing new wetland areas while maintaining highly productive agricultural land.

C. This chapter provides guidance during the planning and implementation stages for artificial drainage practices. These stages could involve investigations, surveys, planning, design, specifications, installation, and the operation of the systems for proper water management. Although most of this chapter concentrates on agricultural drainage, which is the management of surface and subsurface water on agricultural and closely related lands, the principles apply to urban conditions as well. This chapter is not intended to provide guidance for large drainage channels.

(1) Need for Soil and Water Management

- (i) Visual evidences of inadequate drainage include surface wetness, lack of vegetation, crop stands of irregular color and growth, variations in soil color, and salt deposits on the ground surface (figs. 14-1 and 14-2).

Figure 14-1: Cropland in Need of Drainage Maintenance



Figure 14-2: Field Drainage System in Need of Maintenance



- (ii) The need for agricultural drainage varies considerably because of differences in climate, geology, topography, soil characteristics, crops, and farming methods.
- (iii) The needed drainage improvements should be determined for each particular site. For example, drainage is needed to complement conservation tillage on naturally wet soils and on some soils that were not excessively wet under earlier tillage practices.
- (iv) Effective drainage is also important to facilitate good water management where environmental conditions dictate a desire to keep soils wetter longer. With uncertain drainage effectiveness, landowners are more likely to keep water tables lower to prevent flooding of crops during periods of high rainfall. Efficient drainage systems can provide a predictable response to management, providing landowners the confidence to keep water higher longer because of the ability to remove water in a timely fashion.
- (v) Ground water drainage can be either natural or artificial. Natural drainage takes place in soils that have a deep hydrological profile and the hydraulic conductivity values are either uniform or increase with depth. Consequently, impermeable soil layers are either absent or located deep. Under such circumstances the ground water table cannot be detected within 6 feet of the ground surface, and artificial drainage is not required.
- (vi) A lack of natural drainage often causes a high-water table and, under some conditions, can cause surface ponding of water. These conditions are the result of a shallow hydrological profile. This indicates the presence of a shallow impermeable layer or that the soil horizon becomes less permeable with depth to the point that percolation is restricted, creating root zone water problems that deter vegetative growth. A high-water table and waterlogging in the soil are often prevalent above an impermeable layer when the rate of rainfall or the rate at which water is added exceeds the permeability of this layer. Artificial drainage systems can be installed to remove the excess water and maintain the water table at an appropriate level for the crops or other vegetation to be grown.
- (vii) Drainage is a practice that can assist in the surface and subsurface management of water. It may be designed to provide numerous benefits other than direct crop benefits. Some additional applications involve:

- Environmental water control for wildlife habitat development or protection.
 - Water quality management
 - Improve site conditions for farmsteads as well as urban and rural communities
 - Improve conditions for application of organic wastes
 - Control of excess salinity in the root zone.
 - Trafficability for farming operations
- (viii) Environmental considerations sometimes require careful attention to soil and water management. Water quality control can be facilitated with a properly installed water table management system. Water control for wildlife habitat enhancement, protection, or development can be improved with carefully prepared drainage practices.
- (2) Natural Resource and Environmental Setting
- (i) The natural resource and environmental setting in relation to the agricultural drainage system must receive balanced consideration. Drainage systems need to be installed without harming the natural resource and environmental setting. The environmental factors that must receive consideration include:
- Water quality control including both protection and improvement
 - Wildlife habitat setting and potential changes because of the drainage
 - Wetlands and their preservation or enhancement
 - Development of new wetlands in the context of a drainage system
 - Mitigation for wetland losses
- (ii) Water quality is often impacted by agricultural, industrial, mining, and urban development. The drainage system can be the collector and carrier for pollutants; thus water quality considerations are critical to the planning of drainage systems. Because the drainage system is a collection facility, it provides an opportunity to treat or control the discharges. Therefore, the system often must be planned in conjunction with other water quality control facilities.
- (iii) Wildlife habitat and wetlands are important natural resources. They provide ecological diversity and critical habitat for many species of plants and animals, some of which are rare, threatened, or endangered.
- (iv) Drainage facilities and other water management systems are planned, installed, and maintained considering wetlands and other land use objectives.
- (3) Factors Affecting Drainage
- (i) The topography, geology, constructed obstructions, or site condition can block or retard water movement and cause poor drainage. Site factors can be placed in several categories and may exist separately or in various combinations. Some of the more important site factors follow.
- (ii) Lack of a natural drainageway or other depression to serve as an outlet. Such sites are common in glaciated, coastal plains and in tidal areas where natural drainage systems are still in the process of development.
- (iii) Lack of sufficient land slope to cause water to flow to an outlet, or natural surface barriers that limit the flow of water. Such sites are: the irregular and pitted surface of glaciated land; depressional areas; and land above dams, constrictions, and natural barriers of valley flood plains.

- (iv) Soil layers of low permeability that restrict the downward movement of water trapped in small surface depressions or held in the soil profile. Many soils have a slowly permeable subsoil, rock formation, or compact (hardpan) layer below the surface either within the normal root zone of plants or at a greater depth. Compact layers can result from human activities (equipment tillage pans) or can occur naturally.
 - (v) Constructed obstructions that obstruct or limit the flow of water. They include roads, fence rows, dams, dikes, bridges, and culverts of insufficient capacity and depth.
 - (vi) Subsurface drainage problems in irrigated areas caused by deep percolation losses from irrigation and seepage losses from the system of canals and ditches serving the area. Deep percolation losses from irrigation may fall in the general range of 20 to 40 percent of the water applied. Losses from canals and ditches vary widely and can range from near zero to 50 percent of the water conveyed.
 - (vii) Many soils in arid and semiarid areas have naturally high concentrations of salts. Also soils in arid and semiarid areas may have high-water tables, which indicates restricted drainage and leads to salt accumulations. High-water tables can be fed by the onsite application of irrigation water, by canal seepage, or by lateral subsurface flows. A primary function of subsurface drainage is to lower and control the water table and keep the salt concentration low in the root zone through leaching. Much of the subsurface drainage work in arid regions is for the control of saline and sodic soil conditions.
 - (viii) Intensive drainage, such as very closely spaced subsurface drains for most soils that have poor internal drainage, is not a cropping problem. Close spacing of drainage-ways on soils in poor condition aids in the establishment and growth of vegetation needed for soil conditioning. The removal of free water in the soil eliminates moisture in excess of that held by soil attraction. Drainage does not remove the capillary water used by growing plants. The depth of the drainageways does control the height of the water table. If the water table is too low in soils that have a low capillary rise, sufficient moisture may not move upward into the root zone. However, this condition is normally desirable in saline and sodic soils that are irrigated.
 - (ix) Special care must be taken with some sandy soils and in most peat and muck areas as they can be over drained. On peat and muck soils, over drainage also increases the rate of subsidence of the soil, which can negatively impact existing drainage systems. Maintaining a high-water table in organic soils minimizes oxidation and subsidence. These soils are also unique in the particular depth of water table that is best for plant growth. This depth should be considered in designing the drainage system.
- (4) Benefits Related to Drainage
- (i) Removal of free water promotes the soil bacterial action essential for manufacture of plant food by allowing air to enter the soil and consequently improving crop production. Plant roots, as well as soil bacteria, must have oxygen. Drainage aids in soil aeration by providing air space in the soil, which allows water passing downward through the soil to carry out carbon dioxide, thus allowing fresh air to be drawn in.
 - (ii) The economic benefits of drainage are typically portrayed by an increased yield coupled with reduced production costs. Uniformity and vigor of crop growth leads to improved drainage and reduced unit production costs (USDA 1987).

- (iii) Surface drainage removes ponded water quickly, thereby allowing the remaining gravitational water to move through the soil. Subsurface drainage accelerates the removal of this gravitational water. Thus, soils with production constraints caused by wetness can become highly productive. If proper leaching operations are used, subsurface drainage can improve the salt affected soils in arid and semiarid regions.
- (iv) Andrew Fogiel, working with Harold Belcher at Michigan State University, conducted a literature search on water table management impacts on water quality (Fogiel and Belcher 1991). The study involved 43 published research reports plus 18 research articles. The conclusions were that:
 - The impact of water table management practices is primarily on receiving surface water.
 - Subsurface drainage systems reduce erosion. Overland flow is reduced while the total surface and subsurface drainage increases at the edge of the field.
 - Subsurface drainage results in significant reduction of sediment and pollutants, primarily phosphorous and potassium not in solution.
 - Subsurface drainage sometimes results in increased nitrate nitrogen concentrations delivered to receiving water; however, controlling subsurface drainage can reduce the nitrate nitrogen delivered.
 - Water table management provides the capability to enhance best management practices that deal with field surface nutrient management and erosion control.
 - Subsurface drainage intercepts downward percolating water, which allows for monitoring water quality and providing treatment if needed.
 - Water table management practices can contribute to reducing nonpoint pollution alone and with other practices.
 - The effect of subsurface drainage on deep ground water quality has not been established because of lack of research and difficulty in monitoring.
 - Research is limited on effects-controlled drainage and subirrigation have on water quality. These systems have been shown to reduce total flow at the edge of the field and agricultural chemical losses to receiving surface water.
- (v) The removal of free water by drainage allows the soil to warm up more quickly because less heat is required to raise the temperature of drained soil. Soil warmth promotes bacterial activity, which increases the release of plant food and the growth of plants. Soil that warms up sooner in the spring can be planted earlier and provide better germination conditions for seeds. Poor surface drainage is shown in figure 14-2.
- (vi) The removal of ground water improves the conditions for root growth. For example, if free water is removed from only the top foot of soil, crop roots will feed in this confined area. However, if free water is removed from the top 3 feet of the soil, this entire depth is available for plant roots to obtain nutrients and moisture. Removing ground water also reduces the amount of surface runoff, thus reducing erosion and the quantity of sediment and associated nutrients and pesticides leaving the land.
- (vii) In humid areas, removing excess subsurface water reduces runoff by allowing water intake on a continuous basis and providing room for moisture to be stored in the soil during prolonged rainstorms or snowmelt. Soil tilth must also be maintained to allow the continued intake to occur. Subsurface drainage can be a part of the total Resource Management System (RMS) needed to reduce or control erosion.

- (viii) The removal of excess subsurface water in humid areas can improve trafficability to facilitate the harvesting of nursery stock during the dormant period. Generally, dormancy coincides with the prolonged winter precipitation period. During prolonged periods of intensive rainfall, improved drainage may allow agricultural wastes to be effectively spread on drained pasture, hayland, or cropland, thus reducing the waste storage time. Care must be taken to prevent compaction of the soil when spreading wastes by tractor drawn equipment during wet periods. Balloon or flotation tires on the equipment effectively minimizes compaction.
- (5) Water Quality Impacts
- (i) Water quality can be enhanced by installation and proper management of controlled drainage systems. The use of control structures in open drainageways to collect sediment benefits downstream surface water by reducing sediment loads and the nutrients and pesticides normally associated with the sediment. Where applicable, control structures in open drainage-ways or subsurface drainage systems can help to hold a water table close to the ground surface during a noncropping season, which helps to develop an anaerobic condition for denitrification. This can benefit downstream surface and ground water quality.
- (ii) Drainage systems are not primarily installed as water quality management tools, but they do have an impact on soil and chemical transport. Where it has been necessary to clear and drain land for agricultural production, research has shown that drainage systems can have a positive impact on some nonpoint pollution problems in comparison to agricultural land without drainage. For example, under certain conditions artificial drainage acts to lower soil erosion by increasing the movement of water through the soil profile and thus reducing runoff. However, some research indicates subsurface drainage expedites the transport of nitrate-nitrogen (nitrate-N) from the soil zone to surface water (Fogiel and Belcher 1991) (ASCE 1995).
- (iii) Based on the published literature, research results on water quality impacts of drainage can be summarized by the following statements that compare agricultural land with subsurface drainage to that without subsurface drainage (Zucker and Brown 1998):
- The percentage of rain that falls on a site with subsurface drainage and leaves the site through the subsurface drainage system can range up to 63 percent.
 - The reduction in the total runoff that leaves the site as overland flow ranges from 29 to 65 percent.
 - The reduction in the peak runoff rate is 15 to 30 percent.
 - Total discharge (total of runoff and subsurface drainage) is similar to flows on land without subsurface drainage, if flows are considered over a sufficient period before, during, and after the rainfall/runoff event.
 - The reduction in sediment loss by water erosion from a site ranges from 16 to 65 percent. This reduction relates to the reduction in total runoff and peak runoff rate.
 - The reduction in loss of phosphorus ranges up to 45 percent and is related to the reductions in total runoff, peak runoff rate, and soil loss.
 - In terms of total nutrient losses, by reducing runoff volume and peak flows, the reduction in soil bound nutrients is 30 to 50 percent.

- In terms of total nitrogen (N) losses (sum of all N species), there is a reduction. However, nitrate-N, a soluble N ion, has great potential to move whenever water moves. Numerous studies throughout the Midwest and Southeast United States and Canada document that the presence of a subsurface drainage system enhances the movement of nitrate-N to surface water. Proper management of drainage water along with selected best management practices (BMP's) help reduce this potential loss.
 - (iv) These results indicate that subsurface drainage is a management tool that reduces the potential for erosion and phosphorus enrichment of surface water from agricultural activities. However, nitrate-N loadings exported from drainage conduits to surface water continue to be a major water quality concern. Agricultural drainage research results related to water quality impacts vary by region of the country; thus the results tend to be region specific, yet they are relevant to similar circumstances. In Ohio State University Extension Bulletin 871 (Zucker and Brown 1998) the basic concepts of water table management are reviewed so the research described for individual states can be better understood.
 - (v) Another 10-year study in the lower Mississippi Valley that supports the above findings showed that subsurface drainage effectively reduced surface runoff from alluvial soil by an average of 35 percent. Associated reductions in losses were 31 percent for soil, 31 percent for phosphorus, 27 percent for potassium, 17 percent for nitrogen, and about 50 percent for pesticides (Bengtson, et al. 1995).
- (6) Agriculture Drainage Setting

The agriculture setting for use of drainage systems is codependent and an integral part of the overall management of the cropping system. The setting is critical to the proper crop development as it is the key tool in providing a proper root zone environment for plant growth. The drainage system is the focal point in a well-planned water table management system and is the key component in a proper salinity control system when adequate natural drainage is not present. In humid and tropical climatic zones, it can facilitate the control of pollutants and improve effectiveness of some soil management practices.

(7) Water Table Control

Water table control is the operation and management of a ground water table to maintain proper soil moisture for optimum plant growth, to sustain or improve water quality, and to conserve water. Controlled drainage is a method of water table management using water management structures. Supplemental water may be added for subirrigation in addition to controlled drainage. Refer to section 650.1418 and Title 210, National Engineering Handbook, Part 624, Chapter 10, “Water Table Control” (210-NEH-624-10) for more information on water table control.

(8) Managing Salinity Conditions

Salinity management in coastal areas and in semiarid or arid climates is paramount to the successful agricultural operations of farming enterprises. The provision of artificial drainage in these areas is related to the need for maintaining a proper salt balance in the crop root zone. Water quality concerns often require the separation of drainage water collected from larger groups of farms to provide the opportunity for proper disposal or reuse of the water. Consideration of reuse options, often on more salt tolerant crops, as well as treatment and disposal options must be a part of planning efforts. Onfarm planning considerations, which are primarily aimed at managing the salinity levels in the crop root zone, cannot stop at this point. The effect of reuse, disposal, or treatment must be considered in the framework of an entire system.

(9) Drainage Setting for Nonagricultural Areas

Drainage for removal of excess water is a practice used in settings other than agriculture under numerous conditions. This practice benefits many recreation areas including sport fields and parking lots. In urban and suburban settings, it is closely related to storm water management, but is also used to facilitate landscaping needs for water management. Buildings and structures often require artificial drainage to provide a stable foundation. Roadways and airfields are other facilities that may require water management systems for drainage. Sliding hillsides and excavated side slopes sometimes require drainage measures to maintain the stability of the slope and protect facilities.

650.1401 Types of Drainage Systems

A. Drainage is accomplished by establishing or accelerating water removal or water table management within the site, by diverting offsite surface or subsurface flows, or by a combination of these. Even though most references relate to agricultural settings, the applicability includes urban areas.

B. Field drainage systems, whether surface or subsurface, generally remove excess irrigation water, leaching water, storm runoff, snowmelt, excess rainfall occurring on the site, or overland flows. Surface water generally is removed by a combination of practices of open ditches, land forming, and underground outlets. Subsurface flows are removed or controlled by open ditches or buried conduits. A lateral drain or system of lateral drains are generally located to lower the water table. The alignment of the drains depends somewhat on costs, topography, design grades, and outlet conditions.

C. Surface drainage Surface drainage involves removal of excess surface water by developing a continuous positive slope to the free water surface or by pumping. It may be accomplished by open ditches, land grading, underground outlets, pumping, or any combination of these that facilitates water movement to a suitable outlet. Drainage by this method applies to nearly level topography where:

- (1) Soils are slowly permeable throughout the profile.
- (2) Soils are shallow, 8 to 20 inches deep, over an impermeable layer.
- (3) Topography consists of an uneven land surface that has pockets or ridges which prevent or retard natural runoff.
- (4) Surface drainage supplements subsurface drainage.

D. Subsurface Drainage

Subsurface drainage is the removal of excess ground water within the soil profile. It is also used to facilitate the leaching of salts from the soil and maintenance of a salt balance. Plastic tubing, clay and concrete tile, and mole drains are used in many cases. Open ditches constructed to an adequate depth and properly located may also be used. Subsurface drainage is applicable to wet soils having sufficient hydraulic conductivity for drainage where a suitable outlet is available, or an outlet can be obtained by pumping.

E. Interception Drainage

Interception drainage systems remove excess water originating upslope, deep percolation from irrigation or rainfall, and water from old, buried stream channels. Interception drains are open ditches or buried conduits located perpendicular to the flow of ground water or seepage. They are installed primarily for intercepting subsurface flow moving downslope. Although this method of drainage may intercept and divert both surface and subsurface flows, it generally refers to the removal of subsurface water.

F. Water Table Management

Water table control systems can be an alternative to single purpose drainage systems. The basic premise is to install certain structural measures and to operate them in a manner that controls the water table at a predetermined elevation. The structural practices can range from installing a flashboard or stoplog structure in the outlet ditch to installing a complete system consisting of land forming, subsurface drain tubing, water control structures, well and pump to provide supplemental water, and observation wells for monitoring.

G. Drainage Pumping

- (1) Pumps or pumping systems have many applications in drainage systems. Pumps may be used as outlets for surface or subsurface drainage when gravity outlets are not available, or the available outlet is not deep enough to satisfy minimum depth requirements. A more complete write-up than that in this chapter is in 210-NEH-624 and in NEH, Section 16, "Drainage of Agricultural Land" (SCS 1971).
- (2) Pumps for water supply are often needed for subirrigation or water table management systems. Wells and pumps for wells are also described in 210-NEH-623 and 210-NEH-650-12.

650.1402 Investigations and Planning

A. When drainage is considered, an investigation is necessary to determine the feasibility of the project. The investigation should provide a clear understanding of the problem, the kinds and amounts of practices necessary, and an estimate of the cost and expected benefits and impacts of the project.

B. This information often can be obtained from a reconnaissance of a small problem area. More detailed examinations and surveys are made where the size of the area, lack of defined drainage pattern, or such special situations as riparian vegetation, wetlands, or rock outcrops may require. Environmental considerations must be a part of the planning process and investigations necessary for habitat enhancement or mitigation and for environmental protection should be an integral part.

C. Reconnaissance

- (1) The first step in analyzing the problem is to visit the area proposed for drainage. Wetland determinations are to be made if not readily available. Determinations related to cultural resources and endangered or threatened species of flora and fauna for the region should also be investigated. If a standard soil survey map of the area is available, it is a valuable source of information. The investigator should walk over the area and become acquainted with the problems, topographic conditions, and physical features. The ideal time to do this is immediately after an intensive rainfall or an irrigation application. The investigator can mark low areas and other important features on a map while in the field. Some field surveys may be needed to identify or locate low areas.
- (2) Special emphasis must be given to ground water investigations for subsurface drainage and water table control systems. The primary purpose of such water management is to lower and control water table levels. At the time of the reconnaissance, a determination is made of the average or usual depth to the water table, as well as the water table level during the growing season. Landowners and operators may have a good estimate of water table levels based on their farming experience. In the absence of such information, local wells can be checked and, if necessary, a few borings can be made at selected locations to get some estimate of water table levels. If a high-water table does exist and subsurface drainage or water table control is recommended, a more detailed investigation is required before planning and designing a system.
- (3) The vegetative cover should be observed and associated with certain ranges of water table levels or surface ponding. Willow, cottonwood, and poplar trees often thrive in high-water areas. Grasses, such as reed grasses and sedges, are generally in these areas, as are many other hydrophytic plants and weeds. The presence of hydrophytic vegetation that typically occurs in wet areas may indicate that a wetland is on the site. The Natural Resources Conservation Service is committed publicly and by policy to help protect wetlands; therefore, technical assistance to plan and install or improve drainage systems on wetlands can be provided as outlined in the National Food Security Act Manual (NFSAM).
- (4) Maps, a hand level, and a soil auger should be used in the reconnaissance. A standard soil survey report, aerial photographs, and county and USGS survey maps are helpful sources of information. They are useful as a guide in recording data, such as soil information, limits of areas to be improved, location of outlets, natural and artificial channels and improvements, probable location of proposed improvements, general land slopes, channel slopes, wetlands to be protected, and watershed boundaries. Pacing or scaling from a map and hand level shots provide a means of estimating approximate channel grades, depths, and sizes. The soil auger, with extensions, provides a means of making essential subsoil examinations and determining water table levels at depths commonly needed for most sites.
- (5) The following items should be noted:
 - (i) Location and extent of any wetlands.
 - (ii) The areas in which crops show damage, as pointed out by the farmer, indicated by the aerial photograph, or noted in personal observations.
 - (iii) Personal observations of unique landscape features, ecologically significant areas, land use patterns, operation (land management) aspects, and site visibility.
 - (iv) Topography and size of the watershed area.
 - (v) Size, extent, and ownership of the area being considered for drainage.
 - (vi) Location of the drainage outlet and its condition.


- (vii) Location, condition, and approximate size of existing waterways.
 - (viii) Presence of cultural resources.
 - (ix) Potential impacts outside the area being evaluated.
 - (x) General character of soil throughout the area needing drainage, including land capability, land use, crops and yields, and salinity or sodicity.
 - (xi) High-water marks or damaging floods and dates of floods.
 - (xii) Utilities, such as pipelines, roads, culverts, bridges, and irrigation facilities and their possible effect on the drainage system (see NEM part 503).
 - (xiii) Sources of excess water from upslope land or stream channel overflow and possible disposal areas and control methods.
 - (xiv) Condition of areas contributing outside water and possible treatment needed in these areas to reduce runoff or erosion.
 - (xv) Condition of any existing drainage system and reasons for failure or inadequacy. Old subsurface drainage systems that have failed because of broken or collapsed sections may well be the cause of a wet area.
 - (xvi) Estimate of surveys needed.
 - (xvii) Type and availability of construction equipment.
 - (xviii) Feasibility
- (6) For small jobs, this information may be obtained by the technician who goes over the land with the landowner. The technician can then obtain engineering and other survey data.
- (7) The intensity of this investigation and the makeup of the investigation party depend upon the size of the area and complexity of the problem. In all cases, as much information as possible should be obtained from local farmers and residents. The investigation must be extensive enough to provide a clear picture of the size and extent of the drainage problem.

D. Physical Surveys

- (1) The size and complexity of the area to be drained determines the kinds and number of surveys needed. For the smaller, simpler jobs, the technician may only need a few elevations at key locations and make a few soil borings to determine soil texture, water table levels, and the need for subsurface drainage. Determine the approximate drainage area and estimate the approximate cost.
- (2) The seasonal considerations of field surveys is important. The dormant period versus cropping and/or irrigation season are major periods to evaluate. Weather patterns and significant rainfall/runoff events should also be evaluated.
- (3) Concepts for physical surveys have dramatically improved in recent years. Laser levels, Geographic Information Systems (GIS), and Global Positioning Systems (GPS) are now common tools to modernize and simplify the physical surveys required for investigation and planning related to maintaining drainage systems. These tools can facilitate the proper development of field information to protect valuable wetland or other habitat areas when working on the maintenance of drainage systems. Information needs for the drainage system are detailed in this section. The most efficient tools to use in obtaining proper and thorough data require judgment and responsibility to assure the information obtained presents the environmental picture in perspective with other resource and development improvement suggestions.

- (4) Figure 14-3 represents an infrared photograph and interpretive sketch showing the extent of subsurface drainage for a field. The infrared method appears to be a promising and cost-effective tool as compared to conventional probe methods. The drain mapping procedure is based on the fact that the soil over subsurface drains dries faster than other soil. This changed moisture condition is shown by a difference in the infrared reflectance. A sketch as shown in figure 14-3 may be developed using a GIS process.

Figure 14-3: Extent of Subsurface Drainage for a Field as Shown by Infrared Photo and Interpretive Sketch (photo: Champaign County Soil and Water Conservation District and the Agricultural Engineering Department, University of Illinois)



- (5) Modern laser surveying equipment is readily available and improves efficiency for obtaining the field survey information. Laser leveling has also been used with drainage trenchers for automatic grade control since the 1960's (USDA, ERS 1987). GPS facilitates the mapping of existing drainage facilities, which also contributes to the efficiency and effectiveness of planning work (Farm Journal 1997). GIS data bases are becoming more common, and the availability of this information can greatly enhance the detail and scope of investigation and planning actions without adding a great deal of extra time. GIS data and systems can provide considerable environmental information and facilitate presentations of planned alternatives. The use of these tools truly helps to make the thorough investigations needed for comprehensive planning alternatives and guidance (FAO 1988).
- (6) The objective of a survey for design purposes is to obtain elevations, topography, and other field information necessary to design the system and prepare plans, specifications, and estimates of quantities of work to be performed. Only the field information needed for this purpose should be gathered.
- (7) Drainage Outlet
- (i) The first major engineering survey job is to determine the location and adequacy of the drainage outlet. Enough level readings and measurements should be made to reach a sound decision. The proper functioning of the entire drainage system hinges upon this point. The following requirements should be met in determining adequacy of outlets:
- The depth of outlet should be such that any planned subsurface drains may be discharged above normal low waterflow. Pumping may be considered as a last alternative.

- The capacity of the outlet should be such that the design flow can be discharged at an elevation at or below the design hydraulic gradeline. If the outlet is a channel, the stage-discharge relationship should be determined taking into consideration the runoff from the entire watershed.
 - The capacity of the outlet also must be such that the discharge from the project will not result in damaging stage increases downstream of the project.
 - The quality of drainage water and its impact on downstream areas should be considered.
 - Submerged outlets may in some cases be desirable. Special care must be taken to obtain the desirable drainage on the cropland, yet keep the outlet free of undesirable vegetation, sediment, and rodent entry. This situation may also be a common practice in tidal areas where the daily water surface fluctuation allows free discharge part of the time and submergence part of the time. Spacing and depth of a drainage system would need to be adjusted to recognize this condition.
- (8) Topographic survey
- (i) Topographic information of the area to be drained must be obtained. This information is used in the flatter areas for planning land forming or for locating field ditches, drains, or other facilities.
 - (ii) The amount and kind of topographic surveys depend upon the drainage problem and the topography of the land. The surveys vary from a detailed grid or contour map to random elevations, valley cross sections, and location of important features. The type of grade control equipment used by local contractors, such as laser, should be considered in determining the need for topographic surveys. Refer to 210-NEH-650-1, “Surveying”, for survey procedures. Some recommended details to observe in obtaining topographic information for drainage include:
 - Obtain elevations at 100 to 300-foot horizontal intervals on flatland, depending on how nearly level the land is and whether the drainage pattern is apparent from inspection. Take additional elevations in all low or depressed areas. The flatter the land, the more important it may be to take elevations at relatively close intervals.
 - Where random ditches are to be used to drain depressions or pockets, the amount of survey data should be varied according to ground conditions. Elevations at close intervals will be necessary if depressed areas are numerous, whereas a few random shots may suffice for areas that have few depressions. In either case the survey should be made in sufficient detail to locate and determine elevations of depressed areas and the best outlets.
 - Physical features of adjacent land should be specified if they affect the drainage of the proposed area. The information should include the location and elevation of the bottom of drainageways, the size of opening and flow line elevations of culverts and bridges, and any other similar information needed to plan the drainage system.

(9) Profile Survey

- (i) The procedure for running profiles is described in 210-NEH-650-1. Slightly different procedures are required if an existing ditch is used or if a new ditch is being considered. The following steps must be followed for profiles where a ditch already exists:
- Obtain elevations of the old ditch bottom natural ground at 100 to 500 foot intervals along the ditch. Elevations of critical points between stations should also be taken. A critical point may be either a high point or a low point that would affect design or system cost.
 - On existing culverts and bridges along the ditch line, obtain the station, inlet and outlet invert elevations, size of culvert (or size of opening if different), length, alignment angle with the ditch, and kind of material (concrete, CMP). Also, obtain elevations of top of road crossing or structures and, in the case of bridges, the elevation of the bottom of stringers. Where bridges will be affected, note the elevation of the bottom of the top footings and of the bridge piers and abutments along with their condition.
 - Where laterals or tributaries discharge into the ditch, note the station and the bottom elevation of the ditch at the point of entrance and any other pertinent data that would be useful in design.
 - Locate, describe, and obtain elevations as required or any other physical features along the ditch that will affect the design, such as cattle ramps, fences, surface flow entering ditch, and rock outcrops.
 - Obtain soil information for channel stability considerations.
- (ii) Profiles on new ditch lines may differ from profiles of existing ditches. Information and elevations along the proposed ditch line should be obtained as specified for existing ditches.

(10) Cross Sections

- (i) A detailed procedure for surveying cross sections is described in 210-NEH-650-1. Some guidelines include:
- Individual shots should be taken at all prominent breaks to accurately reflect the ground surface.
 - Cross sections should be taken at intervals of 100 to 500 feet on existing ditches, depending on the irregularity of topography and the variation in ditch size. Cross sections may show elevation and extent of low areas needing drainage if this information was not obtained by the preliminary profiles. Other needed information is location of utilities, fence lines, roads, land use, and existing landscape features (trees, vegetation) that may affect construction or future maintenance.

(11) Other Field Information

- (i) Other field data that should be gathered at the time of the design survey include:
- The area to be drained delineated on an aerial photograph or other suitable map.
 - The drainage area.
 - The crops to be grown and farm machinery to be used after drainage.
 - Soil borings to a depth of at least 1 foot below the proposed depth of the ditch (unless the characteristics of the soil materials are known for areas in need of surface drainage) and to twice the depth of drain where subsurface drainage is needed.

- Information on frequency and depth of flooding. Drift marks of previous flooding can be seen on trees, culverts, or fence posts. Elevation and frequency of high-water should be obtained if it will have a bearing on the ditch design.

(ii) For more information, see 210-NEH-650-1.

E. Environmental Considerations

- (1) The environmental values of an area must be fully considered when planning to develop a new drainage system or improve an existing system. Alternatives and options should be evaluated from the perspective of the landowner, neighbors, and the community. Alternatives should aim towards balanced and sustainable systems that fit within the natural setting. The action to be taken or that is proposed will be open to the scrutiny of others, and decisionmakers should be aware of potential impacts for each alternative. Agricultural developments, natural resource conservation, biodiversity, wildlife habitat, water quality, economics, health, and social considerations may all play a role in the decision-making process, and appropriate evaluations should be made.
- (2) Water Quality
 - (i) Installation or maintenance of drainage systems can cause changes to the associated ecosystem; thus, care must be taken to consider the options and to know the adverse and beneficial impacts of actions proposed.
 - (ii) The reuse of drainage water can be noted in the salinity control section of this chapter, Applications of Subsurface Drainage. In-depth information on salinity assessment and management is in ASCE Manual 71 (ASCE 1990). Other documents that describe overall water quality issues include Management Guidelines for Agricultural Drainage and Water Quality, published by the United Nations Food and Agriculture Organization and the International Commission on Irrigation and Drainage (FAO 1997). These documents describe the potential for toxic materials in drainage water and reflect on options for controlling potential pollution substances in drainage water.
 - (iii) Research has demonstrated a strong linkage between subsurface drainage and nitrate-N losses to surface water. An obvious, but less economical method to reduce nitrate-N losses is to abandon subsurface drainage systems. The practicality of this method is minimal, however, as crop production would be reduced substantially on millions of acres of productive poorly drained soils in areas similar to the Midwest Region. In addition, sediment and phosphorus concentrations in surface water would increase. Research conducted in the North Central Region (Zucker and Brown 1998) suggests the following strategies would minimize nitrate-N loss to surface water:
 - Implement wetland restoration areas, denitrifying ponds, or managed riparian zones where drainage water could be "treated" to remove excess nitrate-N before discharge into drainage ditches or streams.
 - Design new subsurface drainage systems or retrofit existing drainage systems to manage soil water and water table levels through controlled drainage or subirrigation, lowering concentrations of nitrate-N in shallow ground water. The cost of retrofitting existing systems for subirrigation must be compared to the benefit of increased yields.
 - Use alternative cropping systems that contain perennial crops to reduce nitrate-N losses. Obtaining a market and a satisfactory economic return presents some barriers.

- Fine tune fertilizer N management. Research shows that applying the correct rate of N at the optimum time substantially affects the reduction of nitrate-N losses.
- Improved management of animal manure would contribute to lowering nitrate-N losses in livestock-producing areas. Knowing the nutrient content and application rate of the manure, spreading it uniformly, and incorporating it in a timely manner would all lead to better management and confidence in manure N as a nutrient source.

(3) Wetlands

Drainage systems impact on wetlands is an ever-increasing concern. Drainage equations and water movement relationships can be used to assess impacts to wetland hydrology by artificial drainage. 210-NEH-650-19, “Hydrology Tools for Wetlands Determination”, describes the hydrology tools or procedures for evaluating hydrology related to wetlands and appropriate distance for safe installation of subsurface drainage systems relative to location of wetlands.

(4) Permits

Required permits and regulatory issues must also receive careful attention. The information for these documents or reports is frequently gathered from a multitude of sources, and new field data may be needed to develop proper analytical documentation.

F. Decision Matrix

- (1) Numerous environmental impact assessment suggestions are available and provide guidance in developing a decision matrix. The decision matrix can be a critical tool for helping decisionmakers review options and reach agreements on work that is to be done. In the planning process, several alternative plans must be developed. The first alternative is generally to do nothing, and then more elaborate alternatives are developed that may be increasingly more complex or more expensive. Each of these alternatives has varying degrees of positive or negative impact on a selected list of evaluations. A typical list of evaluation factors includes:
 - Reduce wetness impact to crops
 - Timeliness of field operations in wet areas
 - Minimize impact to downstream landowners
 - Economics
 - Water quality
 - Biodiversity and wildlife habitat
 - Permits and regulatory issues
 - Soil quality and soil erosion
 - Wetland values
 - Social issues
- (2) One or more tables should be developed to display results of the impacts on the selected factors for each alternative plan. These tables or possible graphic displays benefit the decision-making process while working with concerned individuals or groups.

650.1403 Surface Drainage

A. Surface drainage is needed in flatland areas where water floods over the land. Slopes in these areas generally are not great enough for the flowing water to cause erosion; therefore, the object of drainage systems in flatland areas is to remove the excess water before it damages crops. This differs from erosion control work in which the object is to control the erosive velocity of peak flood flows.

B. When improving soils that have very low permeability or reclaiming highly salt affected soils that need drainage, the use of open drains has a practical installation advantage over pipe drainage. At a later stage when the structure of these soils improves and their hydraulic conductivity values become relatively stable, cost effective subsurface pipe drains can be considered.

C. Drainage Runoff

- (1) Ditches for drainage of common field crops generally are designed to remove runoff from the drainage area within a 24-hour period following a rain event. Some surface flooding of the land during this period is permissible.
- (2) Some high-value and specialty crops require a more rapid rate of removal of runoff to prevent crop damage. For these crops, a 6- to 12-hour removal interval may be necessary during the growing season.
- (3) The drainage coefficient is the rate of water removal per unit of area used in drainage design. For surface drainage the coefficient generally is expressed in terms of flow rate per unit of area, which varies with the size of the area.

D. Determining Drainage Runoff

- (1) Curves for determining runoff for drainage design have been prepared for most of the humid areas of the United States. The curves are based on the climate, soils, topography, and agriculture of the particular area. Curves developed by John G. Sutton, known as the SCS drainage runoff curves have been used in the Northern States since the 1930's. The Red River Valley runoff curves, based on the SCS drainage runoff curves and adjusted to the Red River Valley of the North, have been in use for about the same period.
- (2) Other drainage curves have been developed for use in the Southeastern, Southwestern, and Western States. Because of the wide variations in rainfall, soils, crops, and topography, drainage design should be based on drainage coefficients applicable to local conditions. The capacity for design given by most of the curves varies in accordance with the general formula (Cypress Creek equation):

$$Q = CM^{0.83}$$

where: Q = flow in ft³/s for which the drain is to be designed

C = the appropriate drainage curves

M = area in mi² of watershed


- (3) The drainage curves mentioned provided data to develop figure 14-4, which facilitated the application of the Cypress Creek equation on a national basis.
- (4) This equation provides an economical and effective design for open ditches if C is selected properly. See figure 14-4 and figure 14-5, State standards and specifications or local drainage guides for C values to be used.

Figure 14-4: Drainage Curves

	Land use	Drainage curves (C)
Northern humid region	Pasture	25
	Cultivated (grain crops)	37
Southeastern region	Woodland (coastal plain)	10
	Pasture (coastal plain)	30
	Cultivated (coastal plain)	45
	Cultivated (delta)	40
	Riceland	22.5
Red River Valley (MN & ND)	Cultivated	20
Southwestern region	Rangeland	15
	Riceland	22.5
Western region *		

* Capacity for open drains is generally determined by leaching requirements and amount of return flow from irrigation water. If surface runoff from precipitation is involved, the Cypress Creek equation may be used with a value of C from the applicable state drainage guides.

Note: The drainage curves for the Cypress Creek equation ($Q=CM^{0.83}$) have provided economical and effective design values for open drains in the indicated areas of the United States (Source: NRCS NEH, Section 16).

Figure 14-5: Area Application of Drainage Curves

- (5) The capacity for drainage ditches in arid, irrigated areas is generally determined by the leaching requirement and amount of return flow from irrigation water. If surface runoff from precipitation is involved, the above formula with the appropriate value of C may be used. For many ditches in these areas, the depth rather than the capacity required governs the size of the drain.

E. Composite Drainage Curves

Composite curves are used where runoff from the land draining into an open drain must be based on different drainage curves. The design capacity of ditches in these areas can be determined by computing equivalent drainage area information. Using this method, you determine the runoff from the acreage of one type of land and convert it to the equivalent acreage of another type of land so that the acreage may be added together and used to find the discharge from the area.

(1) Example

- (i) A watershed contains 500 acres of land requiring the runoff curve $Q = 45 M^{0.83}$ and 200 acres of land requiring the runoff curve $Q = 22.5 M^{0.83}$. Either the $Q = 45 M^{0.83}$ or $Q = 22.5 M^{0.83}$ curve must be converted, depending on the curve to be used on land below this watershed.
- (ii) Assume the removal rate of this land is $Q = 45 M^{0.83}$. The discharge from 200 acres on the $Q = 22.5 M^{0.83}$ curve is 8.4 ft³/s. This is about 86 acres on the $Q = 45 M^{0.83}$ curve. The total equivalent watershed would be 500 acres plus 86 acres, or 586 acres. The total discharge from 586 acres on the $Q = 45 M^{0.83}$ curve is 42 ft³/s. Therefore, 586 acres and 42 cubic feet per second are used in computations below this watershed.

650.1404 Investigation and Planning of Surface Drainage Systems

A. A surface drainage system may consist of field ditches and/or land forming with ditches and underground pipes to carry the drainage water to the outlet. The drainage system should provide for an orderly removal of excess water from the surface of the land.

B. Open drains may serve any land use. In urban uses they are typically called open drains or surface storm drains, while in agricultural fields they are usually referred to as ditches.

C. Current legislation and regulations require care to avoid environmental damage to existing wetlands. Maintenance of drainage systems is critical to the sustainability of agriculture and for other land uses.

D. Field Ditches

- (1) Field ditches are shallow ditches for collecting and conveying water within a field. They generally are constructed with flat side slopes for ease in crossing. These ditches may drain basins or depressional areas, or they may collect or intercept flow from land surfaces or channeled flow from natural depressions, plow furrows, crop row furrows, and bedding systems. State drainage guides and standards and specifications have criteria regarding side slopes, grades, spacing, and depth of drainage field ditches.

E. Types of Open Drain Systems

- (1) Drains should be located to fit the farm or other land use operations and should have capacity to handle the runoff and not cause harmful erosion. The drain system should cause excess water to flow readily from the land to the disposal drain. Five common drain systems are described in this section.

(2) Random Drain System

This type system is adapted to drainage systems on undulating land where only scattered wet areas require drainage. The ditches should be located so they intercept depressions and provide the least interference with farming operations (fig. 14-6). The ditches should be shallow and have side slopes flat enough for farm equipment to cross. Precision land forming and smoothing help to assure the removal of surface water from less permeable soil.

(3) Parallel Drain System

This type system is applicable to land where the topography is flat and regular and where uniform drainage is needed. The ditches are established parallel but not necessarily equidistant, as shown in figure 14-7. The direction of the land slope generally determines the direction of the ditches. Field ditches are generally perpendicular to the slope, and laterals run in the direction of the slope. The location of diversions, cross slope ditches, and access roads for farming equipment can also influence the drain location. Spacing of the field ditches depends upon the water tolerance of crops, the soil hydraulic conductivity, and the uniformity of the topography. Land forming can reduce the number of ditches required by making the topography more uniform. Where possible, spacings should be adjusted to fit the number of passes of tillage and harvesting equipment.

(4) Cross Slope Drain System

This system is used to drain sloping land, to prevent the accumulation of water from higher land, and to prevent the concentration of water within a field. The field ditches work best on slopes of less than 2 percent. The drain is located across the slope as straight as topography will permit (fig. 14-8). The spacing of these ditches varies with the land slope and should be based on State drainage guides. The excavated material should be placed in low areas or on the downhill side of the drain. Land forming or smoothing between the ditches improves operation of the system by preventing the concentration of flow and the occurrence of ponding.

(5) Bedding

- (i) Bedding resembles a system of parallel field ditches with the intervening land shaped to a raised, rounded surface (fig. 14-9). This drainage system generally is used where slopes are flat, and the soil is slowly permeable and where other types of drainage are not economically feasible. A bedding system generally is in small land areas and is installed using farm equipment.
- (ii) Beds are established to run with the land slope or in the direction of the most desirable outlet. Local information should be used to determine the width of beds, the crown height, construction method, and maintenance.

(6) Narrow Raised Beds

A narrow bed system has a raised bed wide enough for single or double cropping rows to provide an aerated surface profile. This system facilitates surface water movement and aeration of the shallow root zone. When used with plastic covers for weed control, evaporation control, and nutrient management, the narrow bed system can be extremely effective for some cropping systems.

Figure 14-6: Random Drains




Figure 14-7: Parallel Surface Drains






Figure 14-8: Reconstructing Cross Slope Drain System



Typical flat bottom section



Typical V-channel section





Figure 14-9: Surface Drainage Bedding

F. Landforming

- (1) Landforming refers to changing the land surface to ensure the orderly movement of surface water. Land smoothing and precision land forming are used in surface drainage to improve the effectiveness of the drainage system.
- (2) Land Smoothing
 - (i) Removing small irregularities on the land surface using special equipment is termed land smoothing. It does not require a grid survey and includes operations ordinarily classed as rough grading.
 - (ii) Land smoothing is an important practice for good surface drainage. It eliminates minor differences in field elevations and shallow depressions without changing the general contour of the ground surface appreciably. It results in better drainage, generally with fewer surface ditches, and enables farm equipment to be operated more efficiently. Smoothing also reduces ice crusting in winter.
 - (iii) Soils to be smoothed must have characteristics that allow small cuts. Except for isolated spots handled by prior rough grading, land smoothing operations seldom involve cuts and fills of more than 6 inches. High and low spots generally are visible to the eye without use of an engineer's level. However, sufficient spot elevations should be taken, and adequate planning done to assure that water will readily move to the field ditches and laterals without ponding.

- (iv) Land smoothing is accomplished best by special equipment, such as the landplane or leveler, which can work efficiently to tolerances of 0.1 foot or less. This degree of accuracy is necessary to remove irregularities from flat land. Rough grading for land smoothing can be done with farm tractors and scrapers or with a landplane. In making cuts, avoid removing all topsoil from any area. It is better to take thin layers from a larger area. Where fills from rough grading exceed 6 inches, make an allowance for settling. The allowance is related to the types of soil and soil conditions and may be given in the local technical guides. Final smoothing operations may be deferred until compaction or natural settlement of such areas has taken place.
- (3) Precision Landforming
 - (i) Precision landforming for drainage is reshaping the surface of the land to planned grades so that each row or plane is graded throughout its length to field ditches or other suitable outlets. The land is graded so that rows will carry surface runoff without overtopping. Row or plane grades may be varied within erosive limits to provide drainage with the least amount of grading. Local technical guides provide recommendations on precision landforming for drainage.
 - (ii) **Planning**—Topographic surveys are needed to plan the surface grading and the auxiliary drainage system. 210-NEH-623 and NEH, Section 15, Chapter 12, “Land Leveling”, provides information on surveys, design methods, construction, and maintenance. Local technical guides also provide information and applicable criteria.
 - (iii) **Construction**—Precision land smoothing is accomplished by earth-moving scrapers (fig. 14-10), land levelers, or landplanes (fig. 14-11). The length of most land smoothing equipment varies from 20 to 50 feet, with the longer length giving a more refined job. The large levelers or planes that have an overall span length of about 50 feet may require a crawler-type or 4-wheel drive tractor for power. Those that have a span length of 20 to 30 feet can be pulled with an ordinary wheel-type farm tractor. The smaller machines do a good job on any field but require more trips over the field than the larger machine.

Figure 14-10: Earthmoving Scraper with Laser Grade Control



Figure 14-11: Landplane



- (iv) To facilitate smoothing operations, the ground surface should be chiseled or disked before smoothing and should be free of bulky vegetation and trash. Loosening facilitates the movement of the dirt by the leveler and mixes crop residue into the soil, thus preventing vegetation from collecting on the leveler blade. If the area is in sod, it should be tilled 3 to 6 months before smoothing operations begin, or it should be farmed in a cultivated crop for 1 year before smoothing.
- (v) The roughness of the field and the number of minor depressions determine the number of passes required to produce a smooth field. The land plane should make at least three passes; one pass along each diagonal and a final pass generally in the direction of cultivation.
- (vi) The first year after smoothing, settlement may occur in large depressions that were filled. On relatively flat fields, this settlement can produce pockets that collect and hold water. The field should be observed the year after smoothing. If pockets have developed, at least three more passes should be made with special emphasis on the settled areas.
- (vii) In areas where exposing the subsoil is necessary, you should remove and stockpile the topsoil, do the reshaping, and then replace the topsoil.

650.1405 Design of Open Drains

- A. State drainage guides, standards, and specifications give criteria for side slopes, grades, spacing, and depth of drainage field ditches
- B. Mains and laterals are open ditches constructed to dispose of surface and subsurface drainage water collected primarily from surface field ditches and subsurface drains. They can also intercept ground water, help to control ground water levels, or provide for leaching of saline or sodic soils.

C. Factors affecting the size and shape of ditches are drainage runoff, hydraulic gradient, depth, bottom width, side slopes, roughness of the drain bed and banks, and limiting velocities. Local experience incorporated in the State drainage guide generally dictates the design factors for ditches.

D. Drainage Runoff

- (1) Runoff is determined above and below the outlet of contributing ditches and streams, at points of change in the channel slope, at culverts and bridges, and at the outlet.
- (2) Runoff calculations generally begin at the upper end of the drain and proceed downstream. An empirical procedure, termed the 20-40 rule, should be used in computing the required capacity for a drain below a junction with a lateral. For large drainage areas, the application of the procedure may have considerable effect on the drain design. In small areas the change in required drain capacity may be so small that the procedure need not be applied. Experience in applying the 20-40 rule will guide the designer in its use. The rules for computing the required capacity for a drain are:

(3) **Rule 1**

Where the watershed area of one of the ditches is 40 to 50 percent of the total watershed area, the required capacity of the channel below the junction is determined by adding the required design capacity of each drain above the junction. This is based upon the assumption that the flows from two watersheds of about the same size may reach the junction at about the same time, and that therefore the drain capacity below the junction should be the sum of the two flows. This rule should be used in all cases for watershed areas of less than 300 acres.

(4) **Rule 2**

Where the watershed area of a lateral is less than 20 percent of the total watershed area, the design capacity of the drain below the junction is determined from the drainage curve for the total watershed area.

(5) **Rule 3**

Where the watershed area of a lateral is from 20 to 40 percent of the total watershed area, the discharge is proportioned from the smaller discharge at 20 percent to the larger discharge at 40 percent. In this range the discharges should be computed by both methods and the difference in cubic feet per second obtained. The design discharge for the channel below the junction should then be obtained by interpolation. This combination of rules 1 and 2 is illustrated in the following example.

(6) Example

- (i) A lateral drain draining 350 acres joins a drain draining 650 acres, making a total drainage area below the junction of 1,000 acres. One of the watersheds is 35 percent of the total watershed. Using rule 3, assume that the curve developed from $Q = 45 M^{0.83}$ applies. Find the discharges using information in figure 14-4 and figure 14-5.
- (ii) The difference between 20 and 40 percent is 20 percent. Thirty-five percent is 15/20 (0.75) of the difference between 20 and 40 percent. Then, 0.75 times 7 ft³/s equals 5.2 ft³/s (use 5 ft³/s). Add 5 ft³/s to 65 ft³/s to arrive at 70 ft³/s for the capacity of the drain below the junction. Note that this value is an interpolation between the results of rule 1 and rule 2.
- (iii) Design flows are required at other points along the drain in addition to those for ditches below junctions. These points will be discussed later in this chapter.
- (iv) Figure 14-12 summarizes the computations and results.

Figure 14-12: Example Computation of Design Flows

Rule	Watershed area (acres)	Runoff $Q = 45 M^{0.83}$ (ft ³ /s)
1	350	27
	650	45
		72 (total)
2	1,000	65
		7 (difference)


E. Drain Alignment

The natural topography and aesthetics should be considered in determining drain alignment. Where it is necessary to change direction of the drain or field ditch, a simple curve should be used (see 210-NEH-650-1). Curves that have a radius greater than 600 feet are desirable, but sharper curves can be used if needed to follow old ditches or swales, to decrease the waste area caused by the use of long radii curves, or to conform to ownership boundaries. Where the drain flows are small and of low velocity, gentle curvature is not as important.

F. Hydraulic Gradient

- (1) The hydraulic gradient is the slope of the hydraulic gradeline (water surface) and is important in determining flow velocity. Proper location of the gradeline is more important as drain flows become greater. The profile of the channel should be plotted showing the location and elevation of control points. The control points help to select the maximum elevation of the hydraulic gradeline desired for the drain. They may include, but are not limited to, the following:
 - (i) Natural ground elevations along the route of the proposed drain.
 - (ii) Location, size, and elevation of critical low areas to be drained. These are obtained from the topographic data.
 - (iii) Hydraulic gradeline for side ditches or laterals established from the critical areas to the design drain. Plot the elevation where the side drain hydraulic gradeline meets the design drain as a control point.
 - (iv) Where laterals or natural streams enter the design drain, use the same procedure as that for hydraulic gradeline for side ditches.

- (v) Bridges across drainage ditches should not reduce the area of the design cross section. Where feasible to do so, the hydraulic gradeline should be placed 1 foot below the stringers of the bridge. The allowable head loss on culverts should be kept low. On agricultural drainage the allowable head loss generally should not exceed 0.5 foot.
 - (vi) Elevations of buildings or other property within the area to be protected from overflow.
 - (vii) If the drain being designed is to outlet into an existing drain or natural stream, the elevation of the water in the outlet drain or stream against which the designed drain must discharge should be used as a control point. The water surface elevation in the outlet ditch may be determined from recorded data, historic observation, or high-water marks. Another method of obtaining this elevation is to determine the depth of flow in the outlet ditch by applying the same flow design basis as that used for the proposed ditch. For small outlet ditches in rather flat topography, the water elevation may be estimated at the bankfull stage.
- (2) Connect control points with a line on the profile. The hydraulic gradeline is drawn through or below the control points. The grades should be as long as possible and should be broken only where necessary to stay close to the control points (fig. 14-13).
 - (3) If the hydraulic gradeline has been well established, it will not be altered except at structures that have head losses. At these control points, the head loss will be shown upstream from the structure as a backwater curve. This will change the hydraulic gradient, although generally for only a short distance.
 - (4) If the channel is in an area of flat topography and the hydraulic gradeline is located near field elevation, the hydraulic gradeline may need to be broken at culverts in amounts equal to the required head, otherwise, the backwater curve above the culvert may cause problems. The problems are compounded if several culverts are within a relatively short channel.

Figure 14-13: Establishing Hydraulic Gradeline

Note: For this design the hydraulic gradient (HG) must be 0.5 feet below natural ground (NG). The control points selected were 101.4 @ sta 35+00 and 102.90 @ sta 72+50.

G. Design methods.

- (1) **Design by reaches**—Drain design may be done by reaches (specific length of ditch). One method is to design the ditch for the required capacity of the lower end of the reach and use that section throughout the reach. If this method is used, the upper end of the reach will be oversized. Reaches should be selected so that oversizing is held to practical limits. To reflect the flow conditions as nearly as possible, the selection of the length of reach is important. To determine the beginning and the end of reaches, you can use one of the following:
 - (i) Tributary junctions where the required drain capacity changes.
 - (ii) A break in grade of the water surface profile.
 - (iii) Divided reach—An increasing drainage area may require that an otherwise long reach be divided into shorter reaches. A knowledge of where water enters the drain, as well as the amount, helps to determine how the reach should be divided.
 - (iv) Bridges or culverts can be used to begin or end a reach.
 - (v) After the hydraulic gradeline has been established, determine the drainage area and the required drain capacity at the upper and lower end of each reach. At this time obtain the drainage area and the required capacity for any planned structure (culvert, side inlet, grade control). This information is used in designing the structure.
- (2) **Point Method**—Drain design by the point method is sometimes preferred. In this method the required depth of the drain is determined at the control points for the discharges at those points. This assumes that the runoff throughout the reach enters uniformly along the reach. In reality, the depth at the beginning and end of a reach differ. The depths are established at points below the hydraulic gradeline, and the bottom of the drain is drawn between the points. The slope of the drain bottom normally is not parallel to the hydraulic gradeline. At points where concentrated flow enters, a change in depth or width, or both, may be required. A transition may also be required at these points.
- (3) **Drain Depth**
 - (i) Factors that must be considered in establishing the drain depth are:
 - Depth to provide the capacity for removing the surface runoff plus freeboard.
 - Depth to provide outlet for subsurface drainage.
 - Depth to clear bridges.
 - Depth to allow for sufficient capacity after subsidence in organic soils.
 - Depth to trap sediment below the elevation of a design flow line.
 - (ii) **Surface Discharge**—

Sufficient depth must be provided for surface runoff to flow freely into the ditch. Where the hydraulic gradeline has been established, as shown in figure 14-13, the depth of the ditch is measured down from the gradeline. Where the ditch bottom grade is established first, the depth is measured upward to locate the water surface. Using this last method, the water surface elevation obtained must be checked in relation to control points. The depth of each reach should be determined to meet the needs of the specific area involved.

(iii) Subsurface Discharge—

Ditches used to serve as outlets for subsurface drains should be deep enough to provide free outfall from the underdrain with at least 1 foot of clearance between the invert of the drain and the normal low water flow in the ditch. Ditches designed to intercept subsurface flows or to serve as an outlet for subsurface drainage should be deep enough to serve these conditions. The required depth sometimes results in the ditch capacity being in excess of the design flow requirements for surface runoff, and the actual hydraulic gradeline may be substantially lower. This often occurs at the upper end of small drainage systems.

(4) **Grade of Ditch Bottom**

- (i) If uniform flow in the ditch is assumed, the ditch bottom grade will have the same slope as the hydraulic gradeline. The required depth of the ditch is determined and measured at points below the hydraulic gradeline. These points are then connected to find the bottom grade of the ditch. This method of locating the ditch bottom is generally satisfactory in designing a new ditch. If this method is used, you may prefer to adjust the bottom grade to eliminate the need for transitions.
- (ii) In reconstruction of existing ditches, the elevation of the existing ditch bottom, the bridge footings, and the soil strata must be considered as control points in establishing the bottom of the designed ditch. At times, it may be more convenient to locate the bottom of the ditch from these control points and measure the design depth up from the bottom to locate the hydraulic gradeline (water surface). Cross sections must be used in deciding upon the hydraulic grade or the ditch bottom. Ditch bottom grades that will be erosive during normal flows are to be avoided.

(5) **Ditch Side Slopes**

- (i) The side slopes of ditches are determined primarily by the stability of the material through which the ditch is dug and by the methods of maintenance to be practiced. Recommended side slopes may be found in many local drainage guides. Maintenance requirements may necessitate modification. The steepest side slopes recommended for ordinary conditions for mains or laterals are as shown in figure 14-14:

Figure 14-14: Steepest Side Slopes Recommended for Ordinary Conditions for Mains or Laterals

Material	Side slope (Horizontal to vertical ratio)
Solid rock, cut section	0.25:1
Loose rock or cemented gravel, cut section	0.75:1
Heavy clay, cut section ^{1/}	1:1
Heavy clay, fill section ^{1/}	2:1
Sand or silt with clay binder, cut or fill section	1.5:1
Loam	2:1
Peat, muck, and sand ^{2/}	1:1

^{1/}Heavy clays in CH soils often experience sliding problems caused by the structure of the clays.

The recommended side slope for these soils is no steeper than 4:1.

^{2/}Silts and sands that have a high-water table in the side slopes will slough due to hydrostatic pressure gradient. The recommended side slope for these saturated conditions is no steeper than 3.5:1.

- (ii) Local information may indicate that steeper side slopes can be used in certain soils; however, flatter side slopes may be desirable for more satisfactory and economical maintenance. Ditch side slopes that can be used with various maintenance methods are given in figure 14-15.

(6) Velocity in Ditches

The velocity in a ditch is ideal if neither scouring nor sedimentation occur. Because flows in most ditches are intermittent, the velocity will fluctuate. Ditches are generally designed for the maximum design flow and the allowable average velocity in the ditch section. Figure 14-16 give the recommended limiting velocities at design flow depth for various soils and material. If the velocity is above these limits, scouring and erosion may take place. Because raw, newly dug ditches may have a lower roughness coefficient (Manning's n) than they will have after some aging of the ditch takes place, they may have higher than design velocities. Where vegetation on the ditch side slopes is slow in developing, the limiting velocities may need to be reduced. Minimum design velocities should not be less than 1.4 feet per second to prevent sedimentation. Short field ditches may be used to capture sediment for a water quality benefit. In this case, design velocity should be less than 1.4 foot per second with provision to return sediment to the field.

Figure 14-15: Ditch Side Slopes Recommended for Maintenance

Type of Maintenance	Recommended Steepest Side Slopes	Remarks
Mowing and grazing ^{1/}	3:1	Flatter slopes desirable
Dragline or backhoe	0.5:1	Generally used in ditches (more than 4 feet deep) that have steep side slopes
Blade equipment	3:1	Flatter slopes desirable
Chemicals	Any	Use caution near crops and open water. Follow manufacturer's recommendations

^{1/} Hydraulically operated booms that have a 10- to 14-foot reach may be used to mow side slopes as steep as 1:1.

Figure 14-16: Permissible Bare Earth Velocities

Soil texture	Maximum velocity (ft/s)
Sand and sandy loam (noncolloidal)	2.5
Silt loam (also high lime clay)	3.0
Sandy clay loam	3.5
Clay loam	4.0
Stiff clay, fine gravel, graded loam to gravel	5.0
Graded silt to cobbles (colloidal)	5.5
Shale, hardpan, and coarse gravel	6.0

(7) Determination of ditch velocity

- (i) Manning's equation is used in determining the average velocity in a ditch section.

$$V = \frac{1.486}{n} R^{0.667} S^{0.5}$$

where: V = velocity (ft/s)

n = roughness coefficient

R = hydraulic radius (ft) = A/P

S = slope (ft/ft)

A = cross-sectional area below hydraulic gradeline (ft²)

P = wetted perimeter (ft)

- (ii) For information on computation, refer to 210-NEH-650-3, "Hydraulics", or use any appropriate computational procedure.

(8) Value of Roughness Coefficient *n*

- (i) The value of *n* is a factor in Manning's formula for computing velocity. It indicates not only the roughness of the sides and bottom of the channel, but also other types of irregularities of the channel, such as alignment and vegetation. The value of *n* is used to indicate the net effect of all factors causing retardation of flow. The selection requires judgement in evaluating the material in which the channel is constructed, the irregularity of surfaces of the ditch sides and bottom, the variations in the shape and size of cross sections, and the obstructions, vegetation, and meandering of the ditch.
- (ii) The NEH, Section 16, relates *n* values to the hydraulic radius and indicates that these values decrease when the hydraulic radius increases. Figure 14-15 gives the recommended values of *n*. They are the values that may be expected after aging. The *n* value that occurs immediately after construction will be lower than those given in the table. Unless special site studies are available to determine the value of *n*, the figure 14-17 values shall be used.

Figure 14-17: Value of Manning's *n* for Drainage Ditch Design

Hydraulic Radius	<i>n</i>
Less than 2.5	0.040 - 0.045
2.5 to 4.0	0.035 - 0.040
4.0 to 5.0	0.030 - 0.035
More than 5.0	0.025 - 0.030

(9) Ditch Bottom Width

The machinery used for construction of the ditch should be considered in the selection of ditch bottom width. A bulldozer or blade equipment is used to construct V-shaped ditches. Flat bottom ditches frequently are designed if scrapers, hydraulic hoes, or draglines are to be used to construct the ditch. Depth of ditch and soil conditions affect the type of equipment used. Specified minimum bottom widths are often based on the available equipment.

(10) Relationship between Depth and Bottom Width

The most economical ditch cross-section approaches that of a semicircle. A deep, narrow ditch generally carries more water than a wide, shallow ditch of the same cross-sectional area. An excessively wide, shallow ditch tends to develop sand or silt bars, which cause ditch meandering and bank cutting, and a fairly deep, narrow ditch tends to increase velocities and reduce siltation and meandering. Because the cross-section selected is a matter of judgment, all factors involved should be considered. Ditches shall be designed to be stable. In some cases, economy and hydraulic efficiency must be sacrificed in the interest of ditch stability and maintenance.

(11) Calculation of Ditch Capacity

- (i) The volume (Q) of water passing a ditch cross section is calculated in cubic feet per second (ft³/s) and is the product of the flow area cross section (A) in square feet (ft²) and the average velocity in the cross section (V) expressed in feet per second (ft/s). The formula is:

$$Q = AV$$

- (ii) Various curves, tables, and computer software, all based on Manning's formula for velocity, have been prepared to determine ditch capacities (appendix 14A).

(12) Ditch berms

- (i) Berms should be designed to:
- provide roadways for maintenance equipment;
 - provide work areas;
 - facilitate spoil-bank spreading;
 - prevent excavated material from washing back into ditches; and
 - prevent sloughing of ditchbanks caused by placing heavy loads too near the edge of the ditch.
- (ii) The recommended minimum berm widths are as shown in figure 14-18:

Figure 14-18: Recommended Minimum Berm Widths

Ditch depth (ft)	Minimum berm width (ft)
2-6	8
6-8	10
> 8	15

(13) Spoil Banks

Spoil-bank leveling, or shaping is a common and desirable practice. The degree of leveling, the placing of the spoil, and other practices related to the spoil generally are determined locally and are specified in local drainage guides or State standards and specifications.

(14) Bridges and Culverts

- (i) Design criteria for structures required for drainage ditches, or where irrigation canals cross drainage ditches, are specified by the authority responsible for the structure. The capacity requirement for the structure may be for flood flows that are much more intense than the drainage requirement. On some township, private, and field roads the only requirement may be that the structure carry drainage flow. The following information is limited to this type of structure.

- (ii) The structure must meet two requirements:
- They must be of sufficient size and located so as to pass the design flow within the allowable head loss.
 - They must have adequate strength, size, and durability to meet the requirements of traffic. The following formula can be used to compute the minimum culvert length without headwalls.

$$L = W + 2SH$$

where: L = minimum culvert length

W = top width of fill over culvert, not less than levee top width

S = side slopes of fill over culvert

H = height of fill measured from culvert invert

- (iii) Existing structures should be measured to determine their capacity. An existing structure may be considered adequate if it will pass the design drainage flow with a head that does not cause overbank flow above the structure. As a safety factor, new culvert installations generally are designed for 25 percent more capacity than the ditch design. A new bridge should be designed to span the ditch, have the bottom of the stringers placed at least 1 foot above the hydraulic gradeline, and preferably have no piers placed in the center of the ditch.
- (iv) The hydraulic gradeline at structures does not need to be broken as long as the head loss required to pass the design flow does not cause overbank flooding above the structure. The hydraulic gradeline should be adjusted if such flooding will occur. The gradeline may be broken and dropped down at the structure at an amount equal to the head loss.
- (v) Head loss is negligible through bridges where the channel cross section is not restricted. Head loss through culverts ordinarily should not exceed 0.5 foot. It can be reduced by increasing the size of the structure.

(15) Culvert Flow

- (i) Culverts are used for several types of flow. Detailed knowledge of hydraulics is necessary under some situations for the design of culverts. The following situations commonly occur where culverts are used:
- Culverts flowing full with both ends submerged.
 - Culverts flowing full with unsubmerged or free discharge.
 - Culvert flow limited by culvert entrance conditions
- (ii) See 210-NEH-650-3 for design procedure. See also appendix 14B.


(16) Ditch junctions

- (i) The bottom grades of ditches having about the same depth and capacity should be designed to meet at or near the same elevation. The bottom of a shallow, small capacity ditch may be designed to meet a larger ditch at or near the normal or low flow elevation of the larger ditch.
- (ii) A transition is designed where a shallow ditch enters a much deeper ditch. Before beginning a transition, the grade of the shallow ditch generally is designed 10 to 100 feet upstream on a zero grade at the elevation of the deeper ditch. The transition should be on a nonerosive grade not to exceed 1 percent.
- (iii) Where the difference in the elevation of the ditch gradelines is considerable and transition grades seem impractical, a structure should be used to control the drop from the shallow ditch to the deeper ditch. See 210-NEH-650-6, "Structures", for additional information.

(17) Surface Water Inlets to Ditches

All drainage into mains and laterals should be through planned inlets, rather than at random, which can cause rills or severe bank erosion. This may be accomplished by installing chutes, drop spillways, pipe drop inlet spillways, culverts, or other suitable structures (fig. 14-19). For additional information on inlets, see 210-NEH-650-6.

Figure 14-19: Surface Water Inlets




(18) Swinging Watergates, Cattle Guards, and Ramps

Where applicable, watergates, cattle guards, and ramps should be used on open ditches to manage livestock and to protect the ditches. See figure 14-20(a) for a typical watergate plan and figure 14-20(b) for photograph of similar watergate installation for livestock crossing.

Figure 14-20: Watergate

(a) Watergate Plan



(b) Livestock Crossing using Watergates



(19) Ditch design problem. Example—Open ditch design

(i) Given:

- Drainage area is 1,450 acres (fig. 14-18)
- Apply $Q = 22.5 M^{0.83}$ curve on 200 acres
- Apply $Q = 45 M^{0.83}$ curve on 1,250 acres
- Profile of ditch from figure 14-19
- Side slopes (ss) = 2:1
- Value of $n = .045$
- Minimum bottom width (b) = 4.0 feet
- M = area in square miles

(ii) Required: Design of ditch for surface water removal.

(iii) Solution:

- Locate control points and hydraulic gradeline as shown in figure 14-21 and figure 14-22.
- Draw subdivides for reaches and other design points (fig. 14-21) and determine their drainage areas.

Figure 14-21: Watershed Sketch






Figure 14-22: Profile Ditch with Hydraulic Gradient

- Begin preparing figure 14-23 and determine the discharge for design points using the equation. The area above station 87+50 is 0.31 square mile (200 acres), applicable to the curve developed from $Q = 22.5 M^{0.83}$. This is adjusted to 0.134 square mile (86 acres) developed from $Q = 45 M^{0.83}$. This is done so that the upper area can be added to the areas below this point. The "20-40" rules 1 and 2 were applied as necessary.
- Prepare hydraulic computations using figure 14-23. Show the drainage area, discharge in cubic feet per second, side slopes, n values, and hydraulic gradient at each design point.
- Begin with a trapezoidal cross section, using a 4-foot bottom width. Determine the depth and velocity for each design point. This may be done by using computer programs, appropriate hydraulic tables, curves with varying bottom widths, or hydraulic programs for the programmable calculators. Appendix 14A was used for this example problem. The bottom width, depth, and velocity should conform with the previously specified requirements for drainage ditch design. If they do not conform, assume a different bottom width or channel cross-section shape and recalculate.
- To establish the bottom of the ditch, measure the calculated depths downward from the hydraulic gradeline. Figure 14-24 shows drops at stations 25+00 and 75+50 and a rise at station 50+00. This rise is eliminated by continuing the upstream cross section until it blends with the downstream cross section. The bottom is satisfactory for design regardless of the drops; however, the drops should be eliminated by varying the bottom width. Most machine work is not so accurately done that small drops will be detrimental to the ditch. For larger drops, the design should be changed, or a transition section should be installed at the drops.

Figure 14-24: Design Profile

- Bridge at station 25+00—Field information on this existing bridge indicates that the area of flow of the new ditch will not be reduced an appreciable amount and that no head loss will occur at the bridge. Therefore, the hydraulic gradient will not be changed at that point.
- A new crossing is to be established at station 80+50 where $Q = 18 \text{ ft}^3/\text{s}$. Assume that two 60-foot long, 24-inch concrete pipes that have a beveled lip will be installed. Determine the head loss.
- Solution (use appendix 14B at the back of this chapter): The tailwater depth is 26 inches, and the pipe will have a submerged outlet. Figure 14B-3 gives a value of C as 0.75 for a 24-inch concrete pipe, beveled lip entrance. A half of $18 \text{ ft}^3/\text{s}$ is $9 \text{ ft}^3/\text{s}$ for each 24-inch pipe.

- Determine Q/C :

$$\frac{Q}{C} = \frac{9.00}{0.75} = 12$$

- Figure 14B-1 shows that this requires a head of 0.23 foot. The velocity for the pipe is:

$$V = \frac{Q}{A} = \frac{9 \text{ ft}^3/\text{s}}{3.14 \text{ ft}^2} = 2.86 \text{ ft/s}$$

- Figure 14B-7 shows that the upper end of the pipe should be placed 0.14 feet below the water surface or hydraulic gradeline upstream of the culvert.
- Referring to figure 14-24, the downstream end of the pipe will be placed at station 80+20, and the water surface elevation will be 103.21. The upper

end of the pipe will be at station 80+50. The water surface elevation at the upper end of the pipe will be 103.24 plus 0.23, or 103.47. The water surface from this point will curve upstream and intersect the original water surface several hundred feet upstream. It is evident from the profile that this change in water surface will cause no damage upstream.

- The main advantage in using this method of design is that once the hydraulic gradeline is set, various structure sizes may be selected without changing the tailwater elevation and involving only the backwater curve.

650.1406 Construction

A. Open Drain Layout

The amount of staking required depends upon the topography, the size of ditch, the type of equipment used, and the experience of the contractor or cooperator. A centerline stake, slope stakes, and offset reference stakes may be set at every station. Sometimes the centerline cut or fill is marked on the centerline stake. In many cases staking is not required at every station, but a sufficient number of stakes should be set to obtain the intended result. The method used should conform to state requirements.

B. Structures

All culverts and bridges should be installed or rehabilitated immediately after the site has been excavated. The structures should be installed as planned. The bottom of ditches should be rounded to conform to the shape of the culverts. Where multiple pipe culverts are used, the space between the barrels should be at least half the diameter of the culvert. All backfill should be carefully and firmly tamped.

C. Watergates

Swinging watergates should be constructed of light, durable material. They should be hung so that they do not swing through too great an arc before the bottom of the gate rises to the elevation of the water surface. To prevent the gate from becoming grass bound, a clearance of about 6 inches between the gate and the bottom and sides of the ditch is needed. See figure 14-20 for a typical plan of a swinging watergate.

D. Surface Water Inlets

- (1) Pipe overfall structures generally discharge into areas recessed in the banks of the outlet ditch. This is especially necessary if the outlet is a flowing stream. If they are installed in this manner, they will not be damaged by the movement of water, ice, and debris in the outlet; and the flow in the outlet will not be retarded. The installation should be completed by adequately tamping the soil around the pipe. To prevent a failure by washout, the fill over the pipe should be brought up high enough and along the pipe far enough to force any possible overflow water to the sides. This is generally referred to as an island method of installation.
- (2) The installation of inlet structures on fills should be avoided. The pipe needs to be well bedded—the bottom part of the excavation should conform closely to the shape of the pipe. This fine grading should extend up the sides of the pipe to a point where the backfill can be easily reached with a hand or mechanical tamper. All joints should be watertight.

E. Berms, Spoil Banks, and Seeding

The use of the practices of leaving berms on ditches, leveling of spoil, and seeding ditch slopes, berms, and leveled areas varies with the locality. The spoil should be shaped to facilitate maintenance. Where no berm is left and spoil is shaped into a road, the height of the road should be limited to that which will not cause sloughing of the ditch banks. In all cases, the spoil should be shaped so that the minimum amount of water flows directly back into the ditch. Consideration should be given to controlling erosion of the spoil. State standards for the above items should be used (figs. 14-25 and 14-26).

Figure 14-25: Main Drain with Spoil Banks Spread



Figure 14-26: Seeding Newly Constructed Drain



F. Safety

- (1) Contractors are responsible for construction site safety. Federal regulations covering safety for all types of construction are published in the Safety and Health Regulations for Construction, Department of Labor, Occupational Safety and Health Administration. Many state, municipality, and other local agencies have established codes and safety practices regarding construction. These regulations apply to all types of construction including alteration and repair work.
- (2) Personnel and contractors associated with drainage installation should be thoroughly familiar with the safety requirements and follow the required practices, procedures, and standards. Utility companies must be contacted before any excavation activity. See section 650.1415D, Utilities, and NEM part 503.

650.1407 Maintenance

A. A definite maintenance program should be agreed upon when the drainage system is planned because the maintenance methods to be used can materially affect the design. A good maintenance plan should include the practices to be used as well as the approximate time of the year when specific practices are applicable.

B. Unless the growth of vegetation and silting are controlled by regular maintenance, they may quickly decrease the effectiveness of the drain. The capacity of an open drain can be reduced by as much as 50 percent in 1 year by sediment and a heavy growth of weeds or brush.

(1) Mowing

Mowing to control vegetation on spoil banks, berms, and drains is economical and effective if the side slopes are not too steep. For safety, side slopes on which farm tractors are to be operated should be made 3:1 or flatter (4:1) slopes are preferred. Side slopes as steep as 1:1 can be mowed using mowers mounted on hydraulically operated booms (fig. 14-27). Timing and frequency of mowing should consider wildlife values, weed control, and considerations for controlling other vegetative conditions, such as to avoid snow entrapment along traffic lanes and volunteer woody growth.

(2) Burning

Burning in winter or early spring, when the vegetation is dry and the ground is wet, is sometimes used to control undesirable vegetation in drainage ditches. Bridges, plastic pipe outlets, fences, and other property must be protected from burning. Any burning activity should be in compliance with State and local laws. Impacts on air quality should be a major consideration.

Figure 14-27: Maintenance by Mowing



(3) Chemicals

- (i) Chemicals to control undesirable vegetative growth have produced some excellent results and are used by land users and drainage enterprises. Caution should be used in their application to prevent impact to wildlife, crop damage, and water pollution from the drifting chemicals. Broadleaf crops and some truck crops are particularly susceptible to damage. Information on appropriate chemicals is available from local dealers or current USDA publications. Major chemical companies have prepared considerable information relative to usage of specific products.
- (ii) For guidance in the use of chemicals on common ditch bank weeds, refer to the manufacturer's recommendations or local technical guides. Some states have prepared technical guides and herbicide manuals in cooperation with other agencies. The most up to date information available, including data on new herbicides, should be followed. State laws governing use of herbicides must be followed. All chemicals shall be used according to the labeled instructions. Figure 14-28 shows precision application of chemicals for side slope weed control above the waterline of a drain.

(4) Biological

Because of environmental dangers associated with the use of herbicides or burning, the search for other solutions is ongoing. In open channels with permanent water, fish known to consume large quantities of vegetation, such as the Tilapia, are used with good results. This application is very limited; however, a greater awareness of this alternative and a continuing search for acceptable methods are needed.

Figure 14-28: Application of Chemicals for Side Slope Weed Control



(5) Maintenance of Landforming

- (i) Land preparation practices require year-to-year maintenance to retain their efficiency. Once the field is properly prepared to achieve good surface drainage, the ordinary crop cycle involving tillage, planting, cultivating, and harvesting, along with the wind and water action during the year, can disturb the surface enough to impound water and cause crop damage. Because cropping cycle irregularities, such as implement scars, need to be erased before each crop is planted, a leveler or plane should be operated over the area each year. This operation also will take care of settlement in the fill areas and provide a base for a good seedbed.
- (ii) The diagonal method of maintenance is shown in figure 14-29. Using this method, farm operators can cover most fields with two passes of the leveler in the minimum amount of time. They report that this method reduces the maintenance time by about 25 percent. Figure 14-30 shows a type of land smoothing equipment.

Figure 14-29: Land Leveler Operation for Land Smoothing Maintenance




Figure 14-30: Land Smoothing Equipment



650.1408 Subsurface Drainage


A. Subsurface drainage removes or controls free water from the soil surface and below the surface of the ground. The principal function of subsurface drainage is to prevent, eliminate, or control a high-water table. Lowering the water table can improve growing conditions for crops, the condition of the soil surface, and trafficability on the field as well as around the farmstead. It also facilitates tillage practices.

B. Subsurface drainage also provides a period to apply agricultural wastes during high and prolonged rainfall seasons, and it maintains water intake and soil profile storage capacity, thereby reducing runoff during high rainfall periods. This type of drainage functions in irrigated areas to control saline and sodic soil conditions by removing excess salt accumulations, to provide for subirrigation, to help control seepage from canals and laterals, and to remove excess irrigation water from sources upslope as well as onsite. Subsurface drainage is accomplished by various kinds of buried or open drains.

C. Plans

A plan should be made of every subsurface drainage layout. The size and detail of the plan vary in different locations; however, the plan should have the basic information required for the construction of the subsurface drainage system. Figures 14-31 and 14-32 are an example of a subsurface drain plan and layout.

Figure 14-32: Subsurface Drain Plan and Layout



D. Soils

- (1) Subsurface drainage is applicable to saturated soil conditions where it is physically and economically feasible to use buried conduits to remove or control free water from the root zone.
- (2) The need for and the design of subsurface drainage systems are related to the amount of excess water entering the soil from rainfall, irrigation, or canal seepage; the permeability of the soil and underlying subsoil material; and the crop requirements. In soils with slow permeability that causes water to flow slowly into the drain, the drains must be closely spaced. Consequently, installation may be considered too expensive for use of subsurface drains.
- (3) Soils must have sufficient depth and permeability to permit installation of an effective and economical subsurface drainage system. Some sandy soils and peat and muck have large pore spaces that allow rapid movement of water. Wetness occurs in these soils because of a high-water table, particularly in the spring in nonirrigated areas, late in summer, or during the irrigation period. For maximum crop yields, the wetness problem must be corrected by drainage. These soils can be successfully drained.
- (4) Some fine sand soils have insufficient colloidal material to hold the sand particles together. This can cause excessive movement of the particles into the drains. Special precautions, such as filters or envelopes, are often required.
- (5) In highly permeable, coarse sands and some peat soils, excessive lowering of the water table causes a moisture deficiency during periods of drought. Such soils have limited capillary rise and are unable to deliver water up into the plant root zone of certain crops if the water table falls much below the root zone. Water table control systems should be used for these conditions.
- (6) Other soil conditions make construction of drains hazardous or impractical. In some soils, boulders or stones make drainage costs prohibitive. In others, the topsoil is satisfactory, but it is underlain by unstable sand at the depth where drains should be installed, thus making installation more difficult. A chemical action, which takes place in soils that have glauconite, iron oxide, or magnesium oxide, can cause drain joints or perforations to seal over.
- (7) In soils where iron is present in soluble ferrous form, ochre deposits in drain lines can be a serious problem. If the problem is recognized, it can be solved by making adjustments in design and maintenance of the drainage system.
- (8) Ochre is formed as a combination of bacterial slimes, organic material, and oxidized iron. It is a highly visible, red, gelatinous, iron sludge that often occurs in the valleys of the corrugations of drain tubing as well as at the drain outlets.
- (9) Soil conditions that contribute to ochre formation have been identified throughout the United States. Studies have shown a relationship among soil types, iron ochre, and related sludge deposits in subsurface drain lines. Four known sludge deposits are associated with bacterial activity in subsurface drains—ochre, manganese deposits, sulfur slime, and iron sulfide. Iron deposits, collectively named ochre, are the most serious and widespread of the sludge deposits. The ochre and associated slimes are a sticky mass that is generally red, yellow, or tan. This sticky mass can clog drain entry slots, drain envelopes, and the valleys of the corrugations between envelope and inlet slots. Such elements as aluminum, magnesium, sulfur, and silicon are often present.

- (10) The soils that tend to show the most hazard for ochre formation are fine sand, silty sand, muck or peat that has organic pans (spodic horizons), and mineral soils that have mixed organic matter. Those that have the least potential hazard of ochre are silty clay and clay loam. Sites used for spray irrigation of sewage effluent and cannery plant wastes generally furnish sufficient iron and energy for reduction reactions; therefore, the potential hazard of ochre deposits is serious.
- (11) In certain areas of the western United States, manganese, when present under suitable conditions in the ground water, can form a drain-clogging, gelatinous black deposit. Manganese has not been a serious problem in the Eastern United States.
- (12) Sulfur slime is a yellow to white stringy deposit formed by the oxidation of the hydrogen sulfide in ground water. This slime has not been a serious problem in most agricultural drains. It is most frequent in muck soils. It may be on sites designed for subirrigation if the well water used for irrigation contains hydrogen sulfide.

E. Economics

- (1) Some soils can be drained satisfactorily, but the installation cost of drainage structures is so great that the benefits derived do not justify the expense. In most instances, drain spacing of less than 40 feet for relief (field) drainage can be justified where high value crops or substantial indirect benefits are involved. For example, indirect benefits should be considered where the drying of soil in orchards makes it possible for spray rigs and harvesting equipment to be used without bogging down and where agricultural wastes can be applied during high and prolonged rainfall periods.
- (2) Some soil can be drained satisfactorily, but inherent productivity is so low that yields do not justify the expense. Suitable outlets and disposal for drainage effluent may not be available at an acceptable cost. Even if returns from increased crop yields and reduction in the cost of production should pay for drain system installation within 5 to 10 years, the financial ability of the land user may not allow such an investment. Final economic decisions should be made by the landuser based on best estimate of cost and benefits.

F. Use of Local Guides

Drainage recommendations for the varied soil types, soil conditions, crops, and economic factors can be made only in general terms. Because investigational procedures, planning, and methods of improving drainage conditions differ in many sections of the country, local technical guides and State drainage guides should be consulted for recommendations and procedures for agricultural drainage. Local and State regulations for disposal of drainage water must be complied with.

650.1409 Applications of Subsurface Drainage

A. Field Drainage

- (1) Relief drains are those installed to remove excess ground water percolating through the soil or to control a high-water table. They should systematically lower the water table for an area. The drains may be aligned parallel or perpendicular to the direction of ground water flow.
- (2) Relief drains will develop similar drawdown conditions on either side of the drain, and, if the soil is homogeneous, the water table on either side will be the same at equal distances from the drain.

B. Interception Drainage

Interception drains are installed at right angles to the flow of ground water to intercept subsurface flows. The drainage is applicable to broad, flat areas that are wet because of seepage from canals or adjoining highlands. Drains for interception of seep planes must be located properly to dry wet areas caused by upslope water. Seep planes are first located by soil borings, and then the drain is located so that continuous interception of such seep planes, adequate soil cover over the drain, and uniform grade to an available outlet are established. In steeply graded depressions or draws, a layout may include a main or submain drain in the draw or to one side of the draw, with the interceptor lines across the slope on grades slightly off contour.

C. Drainage by Pumping

- (1) The objective of all subsurface drainage is to remove or control excess water from the root zone of the crop. This generally is accomplished by installing subsurface drains or open ditches. Water table levels may also be controlled by pumping from the ground water reservoir to maintain the upper limit of the water table level. In some irrigated areas where irrigation water is obtained from wells, irrigation and drainage may both be affected by the pumping of wells. This combination of practices is limited to areas where the soil has low salinity and a proper salt balance can be maintained. In salty areas where drainage is accomplished by pumping, the drain water is generally discharged into a natural outlet or planned disposal system and not directly reused for irrigation. In some cases the drain effluent can be used conjunctively with a water source of higher quality, making the water suitable for irrigation use.
- (2) Planning pump drainage can be quite complex. Detailed information on the geologic conditions and the permeability of soil and subsoil material is important. Design involves anticipating what the shape and configuration of the cone of depression will be after pumping. This, in turn, involves spacing of wells with respect to their areas of influence to obtain the desired drawdown over the area to be drained. Experience with this type of drainage indicates that it is costly and consideration of its use may be limited to high-producing lands that have a high net return per acre.

D. Mole Drainage

- (1) Mole drains are cylindrical channels artificially produced in the subsoil without trenching from the surface. Various kinds of plastic liners and methods of installation of the liners have been tried with varying degrees of success. The object of the lining is to extend the life of the mole channel.
- (2) Mole drainage is used in organic soils and soils with a dense, impervious, fine-textured subsoil and normally in more undulating areas. The problem is not the control of a ground water table (which may be very deep), but the removal of excess water from the field surface or from the topsoil. The water reaches the mole channel mainly through fissures and cracks formed during installation of the mole opening. The outflow from mole drainage systems differs considerably from that of subsurface drainage systems controlling the ground water table. Normally, the outflow from mole drainage systems show a quick response to rainfall or irrigation water; thus, as the water application or rainfall event ceases, the outflow ends quickly. The time lag between water intake at the surface and drain outflow is a few hours at most.

- (3) Experience with use of mole drainage in the United States is so variable that it is impractical to describe its use here. Refer to the NEH, Section 16 for general information and to local field office technical guides for specific information.

E. Water Table Management

Water table management is the operation and management of a ground water table to maintain proper soil moisture for optimum plant growth, to sustain or improve water quality, and to conserve water. It is the operation of a subsurface drainage system for the purpose of lowering the water table below the root zone during wet periods (drainage), raising the water table during dry periods (subirrigation), and maintaining the water table during transition (controlled drainage). For more information, refer to section 650.1419.

F. Salinity Control

- (1) Salinity control is practiced for both irrigated cropland and dryland farming operations. The same salt balance principles apply, but the source of the salts and the water source and management must be understood and treated appropriately.
- (2) Drainage for salinity control on dry land commonly intercepts and removes excess ground water upslope of areas in which the subsoil has a high salt content. The excess water may come during high precipitation periods, noncrop growing periods, or during heavy snow accumulation. Removal of the excess water above the seep prevents the accumulation of salts left by the surfacing of the fluctuating water table. Drainage facilities may be used alone or in combination with special agronomic practices to manage the excess water.

G. Dryland Salinity Management

- (1) Management of dryland seeps is described in detail in chapter 17 of the Agricultural Salinity Assessment and Management Manual Number 71 (ASCE 1990). Because interception drainage may play an important role in management of ground water, refer also to the subchapter on interception drainage. Open interceptor drains may be effective and better suit a particular site condition than a subsurface drain.
- (2) Saline or sodic conditions can also occur on nonirrigated land at or near sea level in coastal areas. Controlled drainage structures or pumping systems may be needed to make a drainage system function satisfactorily.

H. Salinity Management for Irrigated Conditions

- (1) The management of saline conditions in irrigated agriculture is practiced more extensively and perhaps better understood. The source of the salts is generally from the irrigation water. As the water is used by evapotranspiration, the salts are either leached below or out of the root zone, or they are left to accumulate in the root zone. If the salts are left to accumulate in the soil profile, a noticeable reduction in yield occurs, depending on the specific crop tolerance. Monitoring salinity level of soil-moisture is shown in figure 14-33. To correct this situation, a natural or supplied source of water is used to leach the salts beyond or out of the root zone. If natural drainage is not adequate to discharge the saline water, then a drainage system needs to be installed. The depth and spacing of subsurface drain tubes are generally much greater in irrigated areas of the Western United States compared to subsurface drainage systems in the humid eastern region.

Figure 14-33: Monitoring Salinity Level of Soil-Moisture



- (2) The proper operation of a productive and sustainable irrigated agriculture, especially when using a saline water source, requires periodic information on the levels and distribution of soil salinity within the crop root zones. Direct monitoring in the field is the most effective way of determining where and when soil salinity conditions need corrective action. Figure 14-33 shows a team of specialists measuring the soil salinity level in the root zone of a cotton crop that is irrigated with moderately saline water. In addition to hand-held equipment in recent years mobile equipment has been perfected to spatially monitor infield soil salinity conditions. Refer to Appendix 14C Salinity Monitoring Equipment.
- (3) Reuse or disposal of saline drainage water has received a lot of attention and special studies in recent years (ASCE 1990). Saline water may be used for more tolerant crops, or the timing of saline water use on crops may be adjusted till the crop growth stage will tolerate the increased saline level without hampering quality or yield. Because reuse of different quality water for sustainability of production is a complex activity, this should only be undertaken after consultation with skilled specialists. Refer to NEH, Section 16; 210-NEH-652-2 and 210-NEH-652-13, and ASCE Manual 71 (ASCE 1990) for additional guidance.

I. Residential and Non-agricultural Sites

A major application of subsurface drainage in nonagricultural settings is for foundation, basement, and lawn areas of residential homes. Refer to the appendix 14F. A recent publication on this subject matter is the Urban Subsurface Drainage Manual, referred to as Manual of Engineering Practice 95 (ASCE, 1998).

650.1410 Investigations and Planning

A. Topography

The amount of surveying needed to obtain topographic information depends on the lay of the land. Where land slopes are uniform, only limited survey data are needed to locate drains. On flat or slightly undulating land, proper location of drains is not obvious, and a topographic survey is necessary. Enough topographic information should be obtained for planning of the complete job. Insufficient data often result in a piecemeal system, which can eventually be more costly to the landowner. Methods for making topographic surveys and maps are covered in chapter 1 of this handbook.

B. Soils

- (1) Unless enough soil borings were taken during the preliminary investigation, more should be taken as part of the design survey. The number of borings necessary depends upon variations in the subsoil material. Borings should be in sufficient number and depth to determine the extent of soil texture variations and to locate any lines of seepage, water movement, or water table elevations.
- (2) Permeability (hydraulic conductivity) of the soil should be determined at each change in soil layers when making the borings. Soil permeability should be determined by the auger-hole or other field methods as described in 650.1411.
- (3) If the hydraulic conductivity tests cannot be performed because a water table is not present, the system could be planned using estimated soil hydraulic conductivity. Hydraulic conductivity can vary significantly within the same soil in any given field; thus, estimates should be used carefully. Estimates can be made for each soil using the Mapping Unit Interpretations Record (MUIR) as shown in figures 14-34 and 14-35. The MUIR lists permeability values that can be used as hydraulic conductivity in lieu of measured values.

Figure 14-34: Estimating Soil Hydraulic Conductivity Using Soil Interpretation Record

NCO128

PORTSMOUTH SERIES

MLRA(S): 153A, 133A, 153B, 153C

REV JHW,ENH, 2-89

TYPIC UMBRAQUULTS, FINE-LOAMY OVER SANDY OR SANDY-SKELETAL, MIXED, THERMIC


THE PORTSMOUTH SERIES CONSISTS OF VERY POORLY DRAINED,NEARLY LEVEL SOILS ON FLATS AND SLIGHT DEPRESSIONS ON THE LOWER COASTAL PLAIN AND STREAM TERRACES IN A REPRESENTATIVE PROFILE,THE SURFACE LAYER IS BLACK FINE SANDY LOAM ABOUT 12 INCHES THICK. THE SUBSURFACE LAYER IS GRAY FINE SANDY LOAM ABOUT 7 INCHES THICK. THE SUBSOIL IS MOTTLED GRAY AND DARK GRAY FINE SANDY LOAM IN THE UPPER PART, SANDY CLAY LOAM IN THE MIDDLE PART,AND SANDY LOAM IN THE LOWER PART THE SUBSOIL IS ABOUT 19 INCHES THICK IS UNDERLAIN BY GRAY SAND AND COURSE SAND TO 72 INCHES. SLOPES RANGE FROM 0 TO 2 PERCENT.

LANDSCAPE AND CLIMATE PROPERTIES											
ANNUAL AIR TEMPERATURE		FROST FREE DAYS		ANNUAL PRECIPITATION		ELEVATION (FT)		DRAINAGE CLASS		SLOPE (PCT)	
								VP		0-2	

ESTIMATED SOIL PROPERTIES													
DEPTH (IN.)	USDA TEXTURE	UNIFIED	AASHTO	FRACT. >10 IN (PCT)	FRACT. 3-10 IN (PCT)	PERCENT OF MATERIAL LESS THAN 3" PASSING SIEVE NO.				CLAY (PCT)			
						4	10	40	200				
0-19	MK-SL, MK-FSL, MK-L	SM, SM-SC, ML, SC	A-2, A-4	0	0	98-100	98-100	65-95	30-65	10-25			
0-19	SL, FSL, L	SM, SM-SC, ML	A-2, A-4	0	0	98-100	98-100	65-95	30-65	5-25			
0-19	SIL	ML, CL	A-6, A-7	0	0	95-100	90-100	85-95	65-80	20-27			
19-35	L, SCL, CL	SC, CL-ML, CL	A-4, A-6	0	0	98-100	98-100	75-95	36-70	20-35			
35-38	LS, SL	SM	A-2	0	0	98-100	98-100	50-70	13-35	8-18			
38-72	SR-COS-LS	SP-SM, SP, SM	A-1, A-2, A-3	0	0	98-100	98-100	45-65	3-25	2-10			

DEPTH (IN.)	LIQUID LIMIT	PLASTICITY INDEX	MOIST BULK DENSITY (G/CM3)	PERMEABILITY (IN/HR)	AVAILABLE WATER CAPACITY (IN/IN)	SOIL REACTION (PH)	SALINITY (MMHOS/CM)	SAR	CEC (ME/100G)	CACD3 (PCT)	GYPSUM (PCT)
0-19	<30	NP-10	1.10-1.30	2.0-6.0	0.15-0.20	3.6-5.5	-				
0-19	<30	NP-7	1.30-1.40	0.6-6.0	0.12-0.18	3.6-5.5	-				
0-19	30-45	10-25	1.50-1.60	0.6-2.0	0.18-0.24	3.6-5.5	-				
19-35	18-40	7-18	1.45-1.55	0.6-2.0	0.14-0.20	3.6-5.5	-				
35-38	<18	NP-4	1.40-1.60	2.0-6.0	0.06-0.10	3.6-5.5	-				
38-72	-	NP	1.40-1.65	6.0-20	0.02-0.05	3.6-6.0	-				

DEPTH (IN.)	ORGANIC MATTER (PCT)	SHRINK-SWELL POTENTIAL	EROSION FACTORS	WIND EROD. GROUP	WIND EROD. INDEX	CORROSION	
						STEEL	CONCRETE
0-19	8-15	LOW	24	5	3	86	HIGH

Figure 14-35: Soil Profile with Calculations of Hydraulic Conductivity Using Soil Interpretation Record

- (4) Saline and sodic problems are most common in arid and semi-arid climates. Where salt crusts are visible or salinity is suspected, the soil should be sampled at various depths. A record of the species and condition of plant cover is important. More details about saline and sodic problems are in ASCE Manual 71 (ASCE 1990) and local drainage guides.
- (5) Soil investigations should be conducted to estimate the maximum potential for ochre development in the planned drainage system.

C. Biological and Mineral Clogging

- (1) The ferrous iron content of the ground water flowing into a drain is a reliable indicator of the potential for ochre development. Soluble ferrous iron flowing in ground water enters a different environment as it approaches the drain and passes through the drain envelope. If the level of oxygen is low, certain filamentous and rod-shaped bacteria can precipitate insoluble ferric iron and cause its incorporation into the complex called ochre. The amounts of iron in ground water that can stimulate bacteria to produce ochre can be as low as 0.2 ppm.
- (2) Laboratory and field methods are available to estimate the ochre potential for a given site. Of particular importance is whether ochre may be permanent or temporary. Temporary ochre occurs rapidly, usually during the first few months after drain installation. If the drains can be cleaned or maintained in functional order, the ochre problem may gradually disappear as the content of iron flowing to the drains is reduced. Such soil environments must be low in residual organic energy sources to prevent the continual release of iron during short-term flooding.
- (3) Permanent ochre problems have been found in profiles with extensive residual iron, such as cemented iron subhorizons or rocks, and from iron flowing in from surrounding areas. Many factors influence ochre deposition, including the pH, type, temperature, and reducing conditions of the soil.

- (4) Certain onsite observations may give clues to potential ochre formation before a drainage system is installed. Surface water in canals may contain an oil-like film that is iron and may contain Leptothrix bacterial filaments. Gelatinous ochre may form on the ditchbanks or bottom of canals. Ochre may also form within layers of the soil. Iron concretions, sometimes called iron rocks, are in some areas. The presence of spodic horizons (organic layers) suggests ochre potential; and most organic soils, such as mucks, have some potential for ochre problems.
- (5) If a site has potential for ochre deposits, certain planning and design practices should be followed to minimize this hazard to the system. No economical, longterm method for effectively controlling this problem is known. For sandy soils where a filter is necessary, a graded gravel envelope is best, although it can become clogged under conditions of severe ochre potential. When synthetic fabrics were evaluated for ochre clogging, the knitted polyester material showed the least clogging.
- (6) A submerged outlet may be successfully used to minimize ochre development with the entire drain permanently under water. The line should be completely under water over its entire length throughout the year. This may require that the drains be on flat grade. The depth of ground water over the drain should be at least 1 foot.
- (7) Herringbone or similar drain designs should have entry ports for jet cleaning.
- (8) Use drainpipe that has the largest slots or holes allowed within the limits of drainpipe and envelope standards. Slots or holes should be cleanly cut and should not have fragments of plastic to which ochre can adhere. Both smooth bore and corrugated pipes can accumulate ochre.

D. Ground Water

Water table contour maps and depth to water table maps are very useful in planning subsurface drainage. The elevation of the water table at selected points, as obtained from borings, is plotted on a topographic map of the area. By interpolation, lines of equal water table are drawn. The result is a contour map of the water table. Where a ground surface contour crosses a water table contour, the depth to the ground water is the difference in elevation of the two contours. Areas that have a range of depths can be delineated on the map. The direction of ground water flow and extent of high-water table areas are also shown on the map. For additional information on the preparation and use of the water table contour maps, refer to 210-NEH-624-10.

E. Outlets.

(1) System Outlets

The starting point in planning a subsurface drainage system is normally the location of the outlet. Drains may discharge by gravity into natural or constructed drains. Any of these outlets are suitable if they are deep enough and of sufficient capacity to carry all the drainage water from the entire drainage system. The adequacy of the outlet should be determined before proceeding with the design of the system.

(2) Capacity and Depth of Open Ditch Outlets

The outlet ditch must have the capacity to remove the drainage runoff from its watershed quickly enough to prevent crop damage. It should be deep enough to allow at least 1 foot of clearance between the flow line of the drain and the normal low water stage in the ditch when drains are installed at the specified depth.

(3) Capacity and depth of subsurface outlets

If existing subsurface drains are used for the outlet, they should be in good condition and working properly. The main drain should have sufficient capacity to handle the proposed drainage system in addition to other systems it serves, and it should be deep enough to permit the new system to be installed at the depth specified.

(4) Pump Outlet

An outlet by pumping should be considered for drainage sites where a gravity outlet is not available. Refer to Section 650.1421 for information on pumped outlets.

(5) Vertical Drain Outlet

- (i) A vertical drain is a well, pipe, pit, or bore, drilled into porous underlying strata, into which drainage water can be discharged. It is sometimes called a drainage well.
- (ii) Wells tap permanent sources of ground water for livestock and domestic use. In some areas, shallow wells are the only reasonable and available water source for domestic use and must be protected from contaminants in agricultural drainage water. Public health laws in some States regulate the use of wells for drainage, and in many cases, prohibit this use because of the potential contamination of ground water and the danger to public health. However, in some parts of the country vertical drainage is a satisfactory solution to drainage water disposal and deep ground water recharge.
- (iii) Where the possibility of using wells for a drainage outlet is considered, an engineer or geologist, or both, should assist in the investigation and planning.

650.1411 Field Drainage System Design

A. To plan a field drainage system, a pattern should be selected that fits the topography, sources of excess water, and other field conditions. The following basic systems may be considered (fig. 14-36).


B. Random System

A random field drainage system is used where the topography is undulating or rolling and has isolated wet areas. The main drain is generally placed in the lowest natural depression, and smaller drains branch off to tap the wet areas. Because such drains often become outlets for a more complete system established in the higher areas of the field, the depth, location, and capacity of the random lines should be considered as part of a complete drainage system. Generally, the logical location of these drains obviously fit the topography.

C. Parallel System

The parallel field drainage system consists of laterals that are perpendicular to the main drain. Variations of this system are often used with other patterns. In many cases, the parallel system is desirable because it provides intensive drainage of a given field or area. It can also be used in depressional or low areas that can be graded before installation of the system.

Figure 14-36: Field Drainage Systems



D. Herringbone System

The herringbone field drainage system consists of laterals that enter the main drain at an angle, generally from both sides. If site conditions permit, this system can be used in place of the parallel system. It can also be used where the main is located on the major slope and the lateral grade is obtained by angling the laterals upslope. This pattern may be used with other patterns in laying out a composite system in small or irregular areas.

E. Drainage Coefficient.

(1) Humid Areas

- (i) Drains should have sufficient capacity to remove excess water from minor surface depressions and the major part of the root zone within 24 to 48 hours after rainfall ceases. The required amount of water to be removed in some specified time is the drainage coefficient. For field drainage, it is expressed as inches of water depth to be removed over a safe period of time, generally 24 hours, or as an inflow rate per unit length of drain. Because of the differences in soil permeability, climate, and crops, as well as the manner in which water may enter the drain (i.e., all from subsurface flow or part from subsurface flow and part from surface inlets), the coefficient must be modified to fit site conditions in accordance with local drainage guides or within the approximate limits as follows:

- Where drainage is uniform over an area through a systematic pattern of drains and surface water is removed by field ditches or watercourses, the coefficient should be within the range as shown in figure 14-37. Figure only the area to be drained as the drainage area.

Figure 14-37: Drainage Coefficients

Soil	Field crops (inches to be removed in 24 hours)	Truck crops
Mineral	3/8 – 1/2	1/2 – 3/4
Organic	1/2 – 3/4	3/4 – 1 1/2

- Where surface water, including roof runoff, must be admitted through surface inlets to the drain, an adjustment in the capacity of the drain is required. Runoff from an area served by a surface water inlet takes place soon after the rainfall and enters the drain ahead of the ground water. In short drainage lines or small systems that have only one or two inlets, the size of the drain may not need to be increased. As systems become larger or the inlets more numerous, an adjustment to the drainage coefficient should be made. The timing of the surface water flow in relation to the entrance of ground water into the drain should be the basis for increasing the coefficient over those shown in figure 14-37.
- A higher coefficient than those given in figure 14-37 is sometimes necessary to hold crop damage to a minimum. Refer to local drainage guides.

(2) Arid Areas

- (i) In areas where rainfall is light, drainage coefficients applicable to local areas are variable and depend upon the quality and amount of irrigation water applied, methods of irrigation, crops to be grown, and characteristics of the soil.
- (ii) Local drainage guides and other information should be used to determine drainage coefficients. However, where experience is lacking, the following formula can be used to estimate drainage coefficients. The deep percolation volume must be accounted for, including leach water that must be added to maintain a favorable salt balance in the soil and the water that is a result of inefficient or excess irrigation. This formula does not account for upslope water sources or upward flux from ground water.

$$q = \frac{\frac{P + C}{100}(i)}{24F}$$

where: q = drainage coefficient, inches/hour

P = deep percolation from irrigation including leaching requirement,
percent (based on consumptive use studies)


C = field canal losses, percent

i = irrigation application, inches

F = frequency of application, days

- (iii) A graphical solution to the formula is provided in the chart in figure 14-38. An example problem solved by graphical method follows.
- (iv) Example: Assume the following
- Total loss ($P+C$) = 30 percent
 - Irrigation application (i) = 6 inches
 - Frequency of application (F) = 8 days
- (iv) Using figure 14-38, find 30 on the left vertical scale; follow horizontally from this point to intersect with line (i) = 6 in. Translate this point vertically to intersect line (F) = 8. Follow horizontally from this point to the right scale and read 0.0092 inches per hour as the drainage coefficient.

Figure 14-38: Curves to Determine Drainage Coefficient, q, for Arid Areas



F. Hydraulic Conductivity

- (1) Any drainage survey should involve a hydraulic conductivity (K) investigation in the field. Twice the depth of drains or the top 7 feet of the soil profile, whichever is less, can be surveyed using the auger-hole method. When using this method, the observation points should be selected according to available soil maps and information on soil morphology and its lateral variation pattern in relation to physiography. Typically, the intensity of a hydraulic conductivity survey for the purpose of project design varies from one hole per 10 acres to one hole per 20 acres, depending on the degree of homogeneity in the obtainable values. Maps should be prepared at a suitable scale showing the K values differentiated, if possible, for hydraulic conductivity above and below drain level and showing depths to an impermeable stratum if one exists. All auger holes should be drilled at least to the depth the drains will be installed. It is advisable to extend one hole in 10 to the relatively impermeable layer (barrier), three holes in 10 to a depth below the drain level, and six holes in 10 to the depth of the drain level. Appendix 14D describes the auger-hole procedure.
- (2) A farm or large field on which the values of hydraulic conductivity are quite uniform may be given an average value by simple calculation of the arithmetic mean. Sometimes the farm or field must be divided into sections, each having values that are uniform but whose averages are different.
- (3) Areas with an average hydraulic conductivity of 0.3 foot per day or less normally are not provided with subsurface drainage. The chosen figure, 0.3 foot per day, is based on economic considerations. Hydraulic conductivity is subject to change with time as a result of alternate drying and wetting of the soil or by changes in the soil structure through chemical or mechanical means, as well as the farming practices.
- (4) Isolated spots of very low hydraulic conductivity may be encountered on farms that are otherwise reasonably permeable. These spots should not be included in the average. The drainage of such localized impermeable mounds is best achieved by draining the surrounding, more permeable soil into which these mounds can then dewater. Installation of subsurface drainage systems in such impermeable soil should be avoided. In some situations, shallow, open field ditches may be feasible. The landowner decides on the feasibility of installing a drainage system with an appropriate drain spacing. Some over or under drainage is inevitable, thus the decisionmaker should be informed of these potential irregularities as decisions are made on spacings.

G. Depth of Impermeable Layer

- (1) The impermeable layer (barrier) is not necessarily a finer textured subsoil. It may be a product of other factors, such as consolidation by the weight of glaciers or a stratification of alluvial sediment.
- (2) The impermeable layer can be defined as a layer with a hydraulic conductivity value of one-tenth or less than that of the soil stratum containing the water table through which the drainage water moves towards the field drains. In that regard, the effects of possible up or downward seepage through the impermeable layer have been neglected, and any lateral seepage (resulting from canal leakage or hillside seepage) is not considered.

- (3) The influence of an impermeable layer on the behavior of a ground water table depends on its depth below the level of field drains and on the drain spacing. The flow pattern of the water moving toward the drain is altered drastically by the impermeable layer if the drain level above the impermeable layer is less than a fourth the spacing between drains. The drains need to be placed closer together to achieve the effect they would have in a deep permeable soil. However, if the depth of the impermeable layer below drain level exceeds a fourth of the drain spacing, the flow system can be treated as if such a layer was absent.

H. Depth and spacing

- (1) The two basic formulas to determine spacing are the steady state and the nonsteady state, also called transient state. A basic form of the steady state equation, referred to as the ellipse equation, is presented in this section. The importance of a good drainage formula for depth and spacing is often overestimated. The transient state formula may better relate actual conditions than the ellipse equation, but the accuracy of results from any of the accepted equations is controlled primarily by the accuracy of the assumed or measured parameters used in the calculations. The accuracy of the input parameters, especially hydraulic conductivity, may be in error by as much as 20 percent; therefore, a minor difference in the result of one equation over another is not that important. Sensitivity analysis of input parameters has been done and documented in conjunction with evaluations of DRAINMOD. For these reasons and to simplify use, it is justifiable to use the presented steady state equation.
- (2) The DRAINMOD computer program can satisfy the need for a more precise analysis of the water table fluctuations and resulting crop impact analysis. If a transient state analysis is desired, refer to appendix 14E. Many field offices have locally developed drainage guides with recommended depth and spacing criteria related to the individual soil series as mapped and published in cooperative soil survey reports.
- (3) Humid areas
 - (i) Generally, the greater the depth of a field drain, the wider the spacing can be between drains. Other factors that help determine the depth and spacing are the soil, climate, subsurface barriers, frost depth, and crop requirements. Where the experience with drain installations is extensive, the depth and spacing of drainage systems in various soils are already well established.
 - (ii) Drains should be deep enough to provide protection against tillage operations, equipment loading, and frost. Initial settlement in organic soils should be considered in depth selection. Main and submain drains must be deep enough to provide the specified depth for outlets of lateral drains. Also, the maximum depth at which drains can be laid to withstand trench loading varies with the width of the trench and the crushing strength of the drain to be used. Allowable maximum depths are given later in this section.

- (iii) In areas where drainage installations and knowledge of effective spacings are limited, the ellipse equation can be used to determine drain spacing.

$$S = \left[\frac{4K(b^2 - a^2)}{q} \right]^{0.5}$$

where (see fig. 14-39): S = spacing of drains, feet,

K = hydraulic conductivity, inches/hour


b = distance from the drawdown curve to barrier stratum at midpoint between the drains, feet

a = distance from drains to the barrier, feet

q = drainage coefficient, inches/hour

- (iv) Note: The units of K and q may also be in inches removal in 24 hours or gallons per square foot per day, but both must be in the same units in this formula. In using this formula for conditions where no known barrier is present, it is assumed that a barrier is present at a depth equal to twice the drain depth.

Figure 14-39: Nomenclature Used in Ellipse Equation



(v) Example: Given-

- 1. Parallel drains are installed at a depth of 6.0 feet ($d = 6$).
- 2. Subsoil borings indicate an impervious barrier at 11 feet below the ground surface ($a = 11.0 - 6.0 = 5.0$ feet).
- 3. Distance from ground surface to drawdown curve desired is 3 feet. Then ($b = 11 - 3 = 8$ feet)
- 4. The hydraulic conductivity of subsurface materials (K), is 1.2 inches/hour.
- 5. The applicable drainage coefficient (q) is $3/8$ inch removed in 24 hours, or 0.0156 inch/hour.

Then:

$$S = \left[\frac{4(1.2)(8^2 - 5^2)}{0.0156} \right]^{0.5} = 109.5 \text{ ft (use 110 feet)}$$

Charts for the graphical solution of the ellipse equation are shown in figure 14-40, sheets 1 and 2. Refer to the figure and solve the above example as follows:

- (vi) Step 1. On figure 14-40 sheet 1, find [$a = 5$] on the bottom scale. Project this point vertically to intersect the curve line [$b = 8$]. From this point, follow horizontally to intersect radial line [$K = 1.2$]. From this point go vertically to intersect the top scale. Read the index number of 380.
- (vii) Step 2. On figure 14-40 sheet 2, find index number (380) on the bottom scale. Project this point vertically to intersect the curve line [$q = 0.0156$]. From this point, follow horizontally to the right vertical scale and read the spacing of [$S = 109$ feet]. [Use 110 feet.]

Figure 14-40: Graphical Solution of Ellipse Equation (sheet 1 of 2)





Figure 14-40: Graphical Solution of Ellipse Equation (sheet 2 of 2)



- (4) Arid Areas
 - (i) For field drainage systems, depth and spacing of drains are given in state drainage guides where experience has been extensive enough to determine the correct figures. Where this information is not available, the ellipse equation, as previously discussed, is used to determine the spacing of field drains.
 - (ii) To control salinity, drains generally are placed deeper in arid and semiarid irrigated areas than in humid areas. The minimum effective depth is 6 feet for medium textured soils and up to 7 feet for fine textured soils, assuming there is no barrier above this depth. This is necessary to maintain the ground water at a depth of 4 to 5 feet midway between the drains. In most cases, the depth of the laterals depends upon the outlet depth, slope of the ground surface, and depth to any barrier.
 - (iii) The depth capacity of the drain-laying machine may limit the depth of the drain unless provisions are made for ramping part of the line. In ramping, a depressed roadway is excavated for the machine to obtain the needed depth in the deeper reaches of the drain line.
 - (iv) If the outlet for the drain is not deep enough to permit its installation to the required depth, then outletting into a sump with an automatic pump cycling may be considered. Refer to section 650.1421 for information on pumped outlets.
- (5) Allowable depths.
 - (i) In most cases subsurface drains should not be placed under an impermeable layer, and they should be located within the most permeable layer. Economic depth should also receive consideration. Economic depth figures can easily be developed locally by evaluating changes in the cost for different depth and spacing ratios for each major soil type. The maximum depth at which subsurface drains can be safely laid varies with the crushing strength of the drain, type of bedding or foundation on which the drain will be laid, the width of the trench, and the weight of the backfill.
 - (ii) Temperature is also a factor to consider for installation and loading of thermoplastic pipe. The maximum depth of cover recommended for subsurface drains is given in the American Society of Agricultural Engineers (ASAE) Engineering Practice 260.4.
 - (iii) Figure 14-41 is provided for guidance on maximum depth. The type of bedding depends upon construction methods. If a drain is installed by backhoe or dragline and the bottom of the trench is not shaped to conform to the drain, special care should be exercised to fill all the spaces under and around the tile or tubing with granular material.
 - (iv) In the ordinary bedding method, the trench bottom is shaped by the shoe of the trenching machine to provide a reasonably close fit for a width of about 50 percent of the conduit diameter. The remainder of the conduit is covered with granular material to a height of at least 0.5 feet above its top or topsoil is placed to fill all spaces under and around the drain. The present method of installing drains using trenching machines is effective, and for practical purposes ordinary bedding may be assumed. The bedding (ordinary) allows the drain to be installed in a deeper or wider trench than if no attention had been paid to the bedding of the drain.
 - (v) For computation of maximum allowable loads on subsurface drains, use the trench and bedding conditions specified and the crushing strength of the kind and class of drain.

Figure 14-41: Maximum Trench Depths for Corrugated Plastic Pipe Buried in Loose, Fine-Textured Soils (feet) *

Nominal tubing diameter (inches)	Tubing quality (ASTM)	Trench width at top of corrugated plastic pipe (feet)			
		(1)	(1.3)	(2)	(2.6 or greater)
4	Standard	12.8	6.9	5.6	5.2
	Heavy-duty	§	9.8	6.9	6.2
6	Standard	10.2	6.9	5.6	5.2
	Heavy-duty	§	9.5	6.6	6.2
8	Standard	10.2	7.2	5.6	5.2
	Heavy-duty	§	9.8	6.9	6.2
10			9.2	6.6	6.2
12			8.9	6.6	6.2
15				6.9	6.2
18					

Note: Depths are based on limited research and should be used with caution. Differences in commercial tubing from several manufactures, including corrugation design and pipe stiffness and soil conditions, may change the assumptions; and, therefore, maximum depths may be more or less than stated above.

* Based on 20 percent maximum deflection.

§ Any depth is permissible for this or less width and for (0.67 ft) trench width for all sizes. Source: ASAE-EP260.4

- (vi) The design load on the conduit should be based on a combination of equipment loads and trench loads. Equipment loads are based on the maximum expected wheel loads for the equipment to be used, the minimum height of cover over the conduit, and the trench width. Equipment loads on the conduit may be neglected if the depth of cover exceeds 6 feet. Trench loads are based on the type of backfill over the conduit, the width of the trench, and the unit weight of the backfill material.

I. Size of Drains

- (1) The size of drains depends upon the required flow and the grade on which they are laid. The required flow is determined from the drainage coefficient and the area or length of drains contributing flow, plus any allowances for concentrated flow entering from the surface, springs, or other sources. The contributing drainage area for a complete drainage system is about the same as the total length of all contributing lines multiplied by the spacing between such lines.
- (2) Random drains in poorly drained depressions are often used later as main drains for a more complete drainage system. Where such expansion is likely, the additional area that such drains would serve should be included in determining the size of the initial random line. Where surface water is admitted directly into a drain by surface inlets, the entire watershed contributing to the inlet should be included. Flow from such watersheds often can be reduced by diversion ditches.


(3) Main Drain

- (i) The required discharge can be determined using figure 14-42 for a given drainage coefficient and area (acres). The required size of the corrugated plastic drainage tubing can be determined directly from figure 14-43. After grade, coefficient, and drainage area have been determined, the size of clay or concrete drain tile required can be determined directly from the tile drainage chart in figure 14-44. The same charts may be used if the required flow and the grade of the drains are known. The size required for all types of drains can be calculated using Manning's equation with the appropriate roughness coefficients (figure 14-45). The example in 650.1411(H)(3)(v) illustrates the use of these charts for the subsurface drainage system shown in figure 14-46.

(ii) Example for main drain (see fig. 14-46):

- Given: A tract of land about 640 by 725 feet is to be drained for general crops. The drainage area is 10.65 acres. The drainage coefficient is 3/8-inch in 24 hours (0.0156 inch/hour). A parallel system that has laterals spaced 66 feet apart, requires 4 lines, 660 feet long; 11 lines, 370 feet long; and 1 line, 200 feet long; making a total of 6,910 feet of drain. The main, as shown from a plotted profile, is on a grade of 0.08 percent and is to be corrugated plastic tubing.
- Required: Size of the corrugated plastic main at the outlet and its capacity.
 - Using figure 14-39, find 10.65 acres in the 3/8-inch coefficient column under Area Drained to determine the discharge of 0.17 cubic feet per second. Using this discharge, enter figure 14-40 and a slope of 0.08 vertical gradeline. The point of intersection lies within the range for an 8-inch drain. The top line of the space marked 8 represents the 8-inch drain flowing full when the hydraulic grade is the grade of the drain. From the intersection of the top of 8-inch range and grade of 0.08 percent, produce a line horizontally to intersect the vertical on the left. The drain flowing full will discharge 0.3 cubic feet per second, which shows that the drain selected will not be flowing full.

Figure 14-42: Subsurface Drain Discharge



Note: Use acres with ft³/s and hectares with m³/s
(Source-ASAE Standard EP260.4)

Figure 14-43: Determining Size of Corrugated Plastic Pipe




Figure 14-44: Determining Size of Clay or Concrete Drain Tile ($n = 0.013$)





Figure 14-45: Values of Manning's n for Subsurface Drains and Conduits

Description of pipe	Values of n
Corrugated plastic tubing	
3 to 8-inch diameter	0.015
10 to 12-inch diameter	0.017
>12-inch diameter	0.020
Smooth plastic, unperforated	0.010 – 0.012
Smooth plastic, perforated	0.010 – 0.012
Annular corrugated metal	0.021 – 0.025
Helical corrugated	0.015 – 0.020
Concrete	0.012 – 0.017
Vitrified sewer pipe	0.013 – 0.015
Clay drainage tile	0.012 – 0.014

Figure 14-46: Subsurface Drainage System



(4) Field or drain lateral

- (i) To compute the size of a lateral, first determine the required discharge for the lateral. The following formula or figure 14-42 can be used. When the discharge is determined, use figure 14-43 to determine the drain size for plastic pipe or figure 14-44 for clay or concrete tile.
- (ii) In the case of parallel drains, the area served by the drain is equal to the spacing times the length of the drain plus one-half the spacing. The discharge can be expressed by the following formula:

$$Q_r = \left[\frac{qS\left\{L + \frac{S}{2}\right\}}{43,200} \right]$$

where: Q_r = Relief drain discharge, ft^3/s

q = Drainage coefficient, in/hr


S = Drain spacing, ft

L = Drain length, ft

(iii) Example:

- Drain spacing – 200 feet (S)
 - Drain length – 3,000 feet (L)
 - Drain coefficient – 0.04 inches/hour (q) (1 inch/day)
 - Drain grade – 0.30 percent
- (vi) Using figure 14-47, find spacing of 200 feet on the vertical scale on the left; follow horizontally to the right to intersect with the drainage coefficient curve 0.04. From that point follow vertically to intersect the length curve of 3,000 feet, then go horizontally to the right to read the discharge of 0.575 cubic feet per second. Using figure 14-44 for plastic tubing, find the above discharge on the vertical scale on the left and look horizontally to intersect the grade of 0.30 percent. An 8-inch drain will be required.
- (v) The drain chart has velocity lines. In the example, the velocity in the drain is between 1.4 and 2.0 feet per second, thus, minimizing sediment accumulation. In a drainage system, different sizes of drains may be needed. Required drain size may change at breaks in grade and changes in tributary area.

Figure 14-47: Curves to Determine Discharge, Q_r , for Main Drain



650.1412 Drain Envelopes

A. Drain envelope is used here as a generic term that includes any type of material placed on or around a subsurface drain for one or more of the following reasons:

- (1) To stabilize the soil structure of the surrounding soil material, more specifically a filter envelope.
- (2) To improve flow conditions in the immediate vicinity of the drain, more specifically a hydraulic envelope.
- (3) To provide a structural bedding for the drain, also referred to as bedding.


B. Refer to section 650.1422 Definitions of Terms for more complete definitions of envelopes (hydraulic envelope, filter envelope, and bedding).

C. Soils in which drains are prone to mineral clogging are commonly referred to as problem soils because the soil particles tend to migrate into the drain. In practice, all very fine sandy or silty soils with low clay content are probable problem soils. Finer textured soils, even with high clay content if the soil is considered dispersed, may present clogging problems in addition to being difficult to drain. Envelope materials placed around subsurface drains (drain envelopes) have both hydraulic and mechanical functions (Dierickx 1992). The protection and stabilizing of the surrounding soil material should be the planned objective as it is not the filter envelope that fails, but the structure of the surrounding soil (Stuyt 1992b). More complete information on drain envelopes is in the Urban Subsurface Drainage Manual (ASCE 1998).


D. Drain Envelope Materials

- (1) Drain envelope materials used to protect subsurface drains include almost all permeable porous materials that are economically available in large quantities. Based on the composition of the substances used, they can be divided into three general categories: mineral, organic, and geotextile envelope materials. Mineral envelopes consist of coarse sand, fine gravel, and glass fiber membranes that are applied while installing the drainpipe. Organic envelopes include prewrapped loose plant materials, fibers, chips, or granules. Synthetic materials are geotextile fabrics specifically manufactured for use in drainage and soil stabilization. Drain envelope materials are most effective when placed completely around the pipe. General drain envelope recommendations are summarized in figure 14-48.
- (2) The practice of blinding or covering subsurface drains with a layer of topsoil before backfilling the trench actually provides many humid area drains with permeable envelope material. Humid area surface soils tend to have a well-developed, stable, and permeable structure that functions well as a drain envelope. In stratified soils, drains are blinded by shaving the coarsest textured materials in the soil profile down over the pipe.

Figure 14-48: Filter Envelope Recommendation Relative to Soil Texture (source USDA)




Comparison of particle size scales



(3) Sand-gravel

Traditionally, the most common and widely used drain envelope that also satisfies the definition of filter envelope material is graded coarse sand and fine gravel. The envelope material may be pit run coarse sand and fine gravel containing a minimum of fines. Properly designed or selected sand-gravel drain envelopes can fulfill all the mechanical, soil stabilizing, and hydraulic functions of a filter envelope. Figure 14-49 shows typical bedding or sand-gravel envelope installations. One example uses an impermeable sheet or geotextile filter. This is used to reduce costs where sand and gravel envelope materials are expensive.

Figure 14-49: Typical Bedding or Envelope Installations



(4) Organic Material

The service life and suitability of organic materials as drain envelopes for subsurface drains cannot be predicted with certainty. Organic matter placed as a drain envelope may also affect chemical reactions in the soil that result in biochemical clogging problems. Where ochre clogging of drains is expected, organic matter should be used with caution.

(5) Synthetic Fiber Materials

In the United States during the 1970's, several dozen installations of thin filter envelopes of fiberglass and spun bonded nylon were monitored with the assistance of the NRCS (SCS at that time). The drain systems typically used 4-inch (100 mm) corrugated polyethylene tubing (CPE). The fiberglass membrane used in these installations did not successfully span the corrugations of the tubing while the spun bonded nylon did. As a result, the fabricator of fiberglass adopted the use of spun bonded nylon. Figure 14-48 was issued to the field offices at that time to provide guidance on the application of the two major types of filter envelopes, which were sand and gravel or thin spun bonded nylon. The figure has been updated to reflect recommendations for geotextiles rather than just nylon.

(6) Prewrapped Loose Materials

Prewrapped loose materials (PLM) used for drain envelopes have a permeable structure consisting of loose, randomly oriented yarns, fibers, filaments, grains, granules, or beads surrounding a corrugated plastic drainpipe. These materials are assembled with the pipe at the time of manufacture as a permeable hydraulic envelope of uniform thickness held in place by twines or netting. The voluminous materials involved are either organic or geotextile.

(7) Prewrapped Geotextiles

- (i) A geotextile is a permeable, polymeric material that may be woven, nonwoven, or knitted. Materials known as geotextiles are widely used as pre-wrapped synthetic drain envelopes. Geotextiles are made of polyester, polypropylene, polyamide, polystyrene, and nylon.
- (ii) Geotextiles differ widely in fiber size or weight, smoothness, and weave density. No single geotextile is suitable as a drain envelope for all problem soils. The materials vary in weight, opening size, fiber diameter, thickness, and uniformity. The geotextiles are commonly wrapped on the corrugated plastic drainpipe in the production plant. The finished product must be sufficiently strong to withstand normal handling that is part of the construction and installation process.

E. Principles of drain envelope design.

(1) Exit gradients in soil near drains

As water approaches a subsurface drain, the flow velocity increases as a result of flow convergence. The increased velocity is related to an increase in hydraulic gradient. The hydraulic gradient close to the drain may exceed unity resulting in soil instability. Using a gravel drain envelope increases the apparent diameter of the drain and, therefore, substantially decreases the exit gradient at the soil and drain envelope interface. A major reason for using a filter envelope is to reduce the hydraulic gradient at the soil and envelope interface, which acts to stabilize the soil in the proximity of the drain system.

(2) Hydraulic Failure Gradient

- (i) The hydraulic failure gradient is the change in hydraulic head per unit distance that results in soil instability, generally a gradient exceeding unity. As long as the flow rate (and the associated hydraulic gradient) in a soil is low, no soil particle movement occurs. If the velocity of waterflow through the soil toward drains is kept below the hydraulic failure gradient, no failure of the drain and drain envelope system should occur.
- (ii) To reduce the hydraulic gradients in the soil near the drain:
 - Increase the effective diameter of the drain by using a hydraulic envelope (i.e., gravel).
 - Increase the perforation area of the drain.
 - Reduce the drain depth and spacing to decrease the possible magnitude of the gradient.
 - Use a geotextile having innerflow characteristics to make the full surface of the corrugated drainpipe permeable. If the geotextile does not have innerflow characteristics, perforations in every corrugation should be required (Willardson and Walker 1979, Salem and Willardson 1992).

- (3) If a soil has a high hydraulic failure gradient, a drain envelope may not be necessary. Many humid area soils do not require use of a drain envelope. If the drain tubes have an opening or perforation area from 1 to 2.5 square inches per foot, the drain functions well without sedimentation problems in structurally stable soils. In some areas, criteria based on the soil clay content and type is used to determine whether a filter envelope is required. Such criteria are based on local experience and field observations.

F. Design of drain envelopes.

- (1) Sand-gravel filter envelope design—
 - (ii) The general procedure for designing a sand-gravel filter envelope for a given soil is:
 - Make a mechanical analyses of both the soil and the proposed filter envelope material.
 - Compare the two particle size distribution curves.
 - Use criteria to determine whether the filter envelope material is satisfactory.
 - (ii) The criteria include:
 - The D_{15} (defined below) size of the filter material should be at least 4 times the diameter of the d_{15} of the base material. (This would make the filter material roughly more than 10 times more permeable as the base material.)
 - The D_{15} of filter material should not be more than 4 times larger than the d_{85} of the base material. (This prevents the fine particles of the base material from washing through the filter material.)
 - (iii) The following gradation limits are recommended:
 - Upper limit of D_{100} is 38 mm (1.5 inches).
 - Upper limit of D_{15} is the larger of 7 times d_{85} or 0.6 mm.
 - Lower limit of D_{15} is the larger of 4 times d_{15} or 0.2 mm.
 - Lower limit of D_5 is 0.075 mm (number 200 sieve).
 - (iv) D_{100} represents the particle size in the filter material for which 100 percent, by weight, of the soil particles are finer (similarly for D_{15} and D_5). The d_{85} and d_{15} represent the particle size in the surrounding base material for which 85 percent and 15 percent, by weight, of the soil particles are finer. In the case of drainage, the base material is the soil.
 - (v) Procedures for determining filter gradation design limits are found in 210-NEH-633-26, "Gradation Design of Sand and Gravel Filters".
 - (vi) Research on filter envelopes show that:
 - If a filter envelope does not fail with the initial flow of water, it is probably permanently safe.
 - The size ratios are critical.
 - Materials with a D_{15}/d_{85} ratio greater than nine always fail.
 - Well graded materials are more successful than uniform sized materials.
 - A well-graded gravelly sand is an excellent filter or filter envelope for very uniform silt or fine uniform sand.
 - It is not necessary for the grading curve of the filter envelope to be roughly the same shape as the grading curve of the soil.

- (2) Sand-Gravel Hydraulic Envelope Design—
 - (i) The criteria for a sand-gravel hydraulic envelope is less restrictive than for a sand-gravel filter envelope as follows:
 - Upper limit of D₁₀₀ is 38 mm (1.5 inches).
 - Upper limit of D₃₀ is 0.25 mm (number 60 sieve).
 - Lower limit of D₅ is 0.075 mm (number 200 sieve).
 - (ii) Pit run coarse sand and fine gravel containing a minimum of fines often meet this criteria.
 - (iii) Sand gradations used for concrete as specified by ASTM C-33 (fine aggregate) or AASHTO M 6-65 will satisfy these hydraulic envelope criteria and will meet the filter envelope requirements for most soils.
- (3) Geotextile Filter Envelope Design
 - (i) In filter envelope applications, the geotextile must physically survive installation, allow adequate flow of water, and basically retain the soil on its hydraulically upstream side. Both adequate flow capacity (requiring an open geotextile structure) and soil retention (requiring a tight geotextile structure) are required simultaneously. Therefore, critical geotextile parameters for filter envelope applications are permittivity, survivability, and soil retention.
 - (ii) **Permittivity**—Unrestricted flow of water through the geotextile is essential. Therefore, the flow capacity (permittivity) of the geotextile should be much greater than the flow capacity of the soil, typically 10 times greater or more. Permittivity values in excess of 1 unit per second (ft³/ft x ft² x sec) are typically required and are determined according to ASTM D 4491 (1992). Permittivity, not permeability, should be specified because permeability measures the rate at which water will pass through the geotextile under a given head without regard to geotextile thickness.
 - (iii) **Survivability**—The geotextile must survive installation without being damaged. AASHTO Designation M288-90 (1990) includes recommendations on minimum physical strength properties for geotextile survivability.
 - (iv) **Soil Retention**
 - The geotextile must prevent excessive loss of fines (soil piping) from the upstream side. This is accomplished by checking the coarser soil particles, which in turn retain the finer soil particles. Numerous approaches can accomplish soil retention, all of which use the soil particle grading characteristics and compare them to the apparent opening size (AOS) of the geotextile. AOS is the approximate largest particle that will effectively pass through a geotextile and is determined by glass ball dry sieving (ASTM D 4751). Both AOS and O₉₅, effective opening size of the envelope pore, represent the apparent opening size in millimeters (mm) or sieve size.
 - The simplest method uses the percentage of fines (soil passing the No. 200 sieve). AASHTO Designation M 288-90 recommends the following retention criteria:
 - (i) Soil ≤ 50% passing the No. 200 sieve AOS of the geotextile No. 30 sieve (O₉₅ < 0.59 mm)
 - (ii) Soil > 50% passing the No. 200 sieve AOS of the geotextile No. 50 sieve (O₉₅ < 0.297 mm)

These criteria should meet most drainage requirements.

- (v) For more critical applications, figure 14-50 recommends O_{95} values based on relative density (D^R), coefficient of uniformity (CU), and average particle size (d_{50}). The terms are defined as:
- d_{50} = soil particle size corresponding to 50% finer
 - CU = coefficient of uniformity = d_{60}/d_{10}
 - d_{60} = soil particle size corresponding to 60% finer
 - d_{10} = soil particle size corresponding to 10% finer
 - AOS = O_{95} apparent opening size of geotextile expressed in millimeters or sieve size

Figure 14-50: Relationships Used to Obtain Fabric Opening Size to Protect Against Excessive Loss of Fines During Filtration (source: Giuard 1982)

Relative density of base material	$1 < CU < 3$	$CU > 3$
Loose ($DR < 50\%$)	$O_{95} < (CU)(d_{50})$	$O_{95} < (9d_{50})/CU$
Intermediate ($50\% < DR < 80\%$)	$O_{95} < 1.5(CU)(d_{50})$	$O_{95} < (13.5d_{50})/CU$
Dense ($DR > 80\%$)	$O_{95} < 2(CU)(d_{50})$	$O_{95} < (18d_{50})/CU$

- (vi) Because the three approaches are restrictive in different degrees, choose one of the three approaches in figure 14-50 (Koener 1986) based on the critical nature of the application.
- (vii) Clogging—Once the geotextile is designed, the next question is “Will it clog?” Obviously, some soil particles will embed themselves within the geotextile structure; therefore, the question really is if the geotextile will completely clog such that the liquid flow through it will be shut off before the soil matrix stabilizes. Laboratory tests, such as the Gradient Ratio Test given in ASTM D 5101, are available to answer this question.
- (viii) Another approach is to simply avoid situations known to lead to severe clogging problems. Three conditions are necessary for a high likelihood of complete geotextile clogging (Koerner 1986):
- cohesionless sands and silts
 - gap graded particle size distribution
 - high hydraulic gradients
- (ix) If these three conditions are present, use of geotextiles should be avoided. A gravel or sand gravel filter envelope can be used.
- (4) Prewrapped Loose Material Filter Envelope Design
- (i) Subsurface drain filter envelopes using prewrapped loose materials may be characterized by pore size distribution, filter thickness, and hydraulic conductivity. Filter thickness and pore size distribution are determined for a natural, compressed condition, but for prewrapped loose materials, the hydraulic conductivity is generally so high that it has no bearing on selection of a filter envelope.
- (ii) Retention criterion defines the capability of a filter envelope to retain soil particles and is expressed as a ratio of a characteristic pore opening size of the filter envelope to a particle size of the soil granular material in contact with the envelope. The characteristic pore opening size of the envelope material is the O_{90} value.

- (iii) Depending on the pore size index O_{90} , prewrapped loose materials are classed into three groups, with recommendations as shown in figure 14-51:

Figure 14-51: Recommendation of Group Classes for Prewrapped Loose Materials

Label	Class	Pore size index range
PLM-XF: XF	extra fine	$0.1 \text{ mm} < O_{90}$
PLM-F: F	fine	$0.3 \text{ mm} < O_{90} < 0.6 \text{ mm}$
PLM-S: S	standard	$0.6 \text{ mm} < O_{90} < 1.1 \text{ mm}$

- (iv) Coil ends are labeled with tape imprinted with identification PLM-XF, PLM-F, or PLM-S.
- (v) Minimum thickness is required to guarantee a homogeneous filter envelope. In addition to these O_{90} ranges, the following minimum filter envelope thicknesses are required regardless of the O_{90} range involved.

Figure 14-52: Minimum Filter Envelope Thicknesses

Material	Minimum filter envelope thickness
synthetic, fibrous	3 mm (e.g., poly-propylene fibers)
synthetic, granular	8 mm (e.g., polystyrene beads)
organic, fibrous	4 mm (e.g., coconut fibers)
organic granular	not yet fixed (e.g., wood chips, sawdust)

- (5) Combination Gravel and Geotextile Filter Envelope Design
- (i) Properly graded gravel or sand gravel material needed for a satisfactory filter envelope may not be readily available, or the cost of handling, including transportation, may be prohibitive. Also, the soil material in the proximity of the subsurface drain may be either difficult or impossible to stabilize with economically available geotextile materials alone. The opportunity to use gravel and geotextile material together for a practical and economic filter envelope should be considered. On many sites the most feasible filter envelope can be designed and constructed from a readily available pit run sand or gravel that would not be satisfactory alone but can be used along with an economical geotextile to satisfy the filter envelope design requirements.
- (ii) A common application incorporates a thin geotextile material adjacent to the pipe with the pit run sand or gap graded gravel surrounding the geotextile. The combination system should be designed using the appropriate criteria given above for each of the filter envelope materials acting independently, resulting in two filter envelopes working in unison. The geotextile is designed to retain the sand or gravel envelope material. The thickness of the sand or gravel envelope should be designed to increase the effective radius of the combination drain envelope to the point that the resulting hydraulic gradient in the soil adjacent to the envelope is reduced satisfactorily.

- (iii) The configuration may be reversed with the geotextile outside the gravel envelope and adjacent to the soil being protected. For this combination the gravel should be coarse enough that migration to or into the pipe is not a concern. The key factor is to increase the area of the geotextile in contact with the soil to satisfactorily reduce the flow velocity associated with the exit gradient. This configuration uses more geotextile per linear length of drain than the combination having the geotextile adjacent to the pipe, but in confined areas it may be the most cost effective.

650.1413 Materials

A. Common subsurface drainpipe materials include plastic, concrete, metal, and clay. Standards are continually updated by standards organizations, such as ASTM and AASHTO, so pipe materials meeting recognized standards adopted by these types of organizations should always be used. Current standards that can be considered follow.

B. Concrete Pipe

- (1) Reinforced and nonreinforced concrete pipes are used for gravity flow systems. Concrete fittings and appurtenances, such as wyes, tees, and manhole sections, are generally available. A number of jointing methods are available depending on the tightness required. Concrete pipe is specified by diameter, type of joint, and D-load strength or reinforcement requirements.
- (2) The product should be manufactured in accordance with one or more of the following standard specifications:
 - (i) ASTM C14/AASHTO M86 (ASTM C14M/AASHTO M86M)—Concrete Sewer, Storm Drain and Culvert Pipe. These specifications cover nonreinforced concrete pipe from 4- through 36-inch (100 through 900 mm) diameters in Class 1, 2, and 3 strengths.
 - (ii) ASTM C76/AASHTO M170 (ASTM C76M/ AASHTO M170M)—Reinforced Concrete Culvert, Storm Drain, and Sewer Pipe. These specifications cover reinforced concrete pipe in five standard strengths: Class I in 60- through 144-inch diameters, and Class II, III, IV, and V in 12- through 144-inch (300 through 3,600 mm) diameters.
 - (iii) ASTM C118 (ASTM C118M)—Concrete Pipe for Irrigation or Drainage. These specifications cover concrete pipe to be used for the conveyance of water under low hydrostatic heads, generally not exceeding 25 feet (75 kPa), and for drainage in sizes from 4- through 24-inch (100 through 600 mm) diameters in standard and heavy-duty strengths.
 - (iv) ASTM C361 (ASTM C361M)—Reinforced Concrete Low-Head Pressure Pipe. These specifications cover reinforced concrete pipe with low internal hydrostatic heads generally not exceeding 125 feet (375 kPa) in sizes from 12- through 108-inch (100 through 2700 mm) diameters.
 - (v) ASTM C412/AASHTO M178 (ASTM C412M/ AASHTO M178M)—Concrete Drain Tile. These specifications cover nonreinforced concrete drain tile with internal diameters from 4 through 24 inches (100 through 600 mm) for standard quality and 4 through 36 inches (100 through 900 mm) for extra-quality, heavy-duty extra-quality, and special quality concrete drain tile.

- (vi) ASTM C444/AASHTO M175 (ASTM C444M/ AASHTO M175M)—
Perforated Concrete Pipe. These specifications cover perforated concrete pipe intended to be used for underdrainage in 4-inch (100 mm) and larger diameters.
- (vii) ASTM C505 (ASTM C505M)—Nonreinforced Concrete Irrigation Pipe with Rubber Gasket Joints. These specifications cover pipe to be used for the conveyance of water with working pressures up to 30 feet (90 kPa) of head.
- (viii) ASTM C506/AASHTO M206 (ASTM C506M/ AASHTO M206M)—
Reinforced Concrete Arch Culvert, Storm Drain, and Sewer Pipe. These specifications cover reinforced concrete arch pipe in sizes from 15- through 132-inch (375 through 3,300 mm) equivalent circular diameters.
- (ix) ASTM C507/AASHTO M207 (ASTM C507M/ AASHTO M207M)—
Reinforced Concrete Elliptical Culvert, Storm Drain, and Sewer Pipe. These specifications cover reinforced elliptical concrete pipe in five standard classes of horizontal elliptical, 18- through 144-inch (450 through 3,600 mm) in equivalent circular diameter, and five standard classes of vertical elliptical, 36- through 144-inch (900 through 3,600 mm) in equivalent circular diameter.
- (x) ASTM C654/AASHTO M176 (ASTM C654M/ AASHTO M176M)—Porous Concrete Pipe. These specifications cover porous nonreinforced concrete pipe in sizes from 4- through 24-inch (100 through 600 mm) diameters and in two strength classes.
- (xi) ASTM C655/AASHTO M242 (ASTM C655M/ AASHTO M242M)—
Reinforced Concrete D-Load Culvert, Storm Drain, and Sewer Pipe. These specifications cover acceptance of pipe design and production based on the D-load concept and statistical sampling techniques.
- (xii) ASTM C789/AASHTO M259 (ASTM C789M/ AASHTO M259M)—Precast Reinforced Concrete Box Sections for Culverts, Storm Drains, and Sewers. These specifications cover precast reinforced concrete box sections from 3-foot (900 mm) span by 2-foot (600 mm) rise to 12-foot (3,600 mm) span by 12-foot (3,600 mm) rise.
- (xiii) ASTM C850/AASHTO M273 (ASTM C850M/ AASHTO M273M)—Precast Reinforced Concrete Box Sections for Culverts, Storm Drains, and Sewers with less than 2 feet (0.6 m) of Cover Subject to Highway Loading. These specifications cover box sections with less than 2 feet (0.6 m) of earth cover in sizes from 3-foot (900 mm) span by 2-foot (600 mm) rise to 12-foot span (3600 mm) by 12-foot (3600 mm) rise.
- (xiv) ASTM C985 (ASTM C985M)—Nonreinforced Concrete Specified Strength Culvert, Storm Drain, and Sewer Pipe. These specifications cover acceptance of nonreinforced concrete pipe design and production based on specified strengths and statistical sampling techniques.

C. Thermoplastic Pipe

- (1) Thermoplastic pipe materials include high density polyethylene (HDPE), poly (vinyl) chloride (PVC), and acrylonitrile-butadiene-styrene (ABS). Thermoplastic pipes are produced in a variety of shapes and dimensions.
- (2) High Density Polyethylene (HDPE) Pipe
 - (i) HDPE pipe is available for gravity and low-pressure flow systems. The application will dictate the quality of the joining system used. Fittings are widely available and can be adapted to many other products. HDPE pipe should be manufactured according to one or more of the following standard specifications:

- (ii) AASHTO M252—Corrugated Polyethylene Drainage Tubing. This specification covers corrugated polyethylene tubing from 3- through 10-inch diameter (75 through 250 mm), couplings, and fittings for use in surface and subsurface drainage applications. Provisions are included for corrugated and smooth interior pipe.
 - (iii) AASHTO M294—Corrugated Polyethylene Pipe, 12- to 48-inch Diameter. This specification covers the requirements of corrugated polyethylene pipe, couplings, and fittings for use in storm sewers and subsurface drainage systems. Provisions are included for both corrugated and smooth interior pipe.
 - (iv) AASHTO MP7-95—Corrugated Polyethylene Pipe 54 and 60-inch Diameter. This specification covers the requirements of corrugated polyethylene pipe, couplings, and fittings for use in storm sewers and subsurface drainage systems. Provisions are included for smooth interior pipe.
 - (v) ASTM F405—Corrugated Polyethylene Pipe and Fittings. This specification covers pipe with 3- through 6-inch (75 through 150 mm) diameter. This product is commonly used for subsurface and surface drainage installations.
 - (vi) ASTM F667—Large Diameter Corrugated Polyethylene Pipe and Fittings. This specification covers pipes from 8- through 24-inch (200 through 600 mm) diameters commonly used for surface and subsurface drainage.
 - (vii) ASTM F810—Smoothwall Polyethylene (PE) Pipe for Use in Drainage and Waste Disposal Absorption Fields. This specification covers smoothwall HDPE pipe, including co-extruded, perforated and nonperforated, from 3- through 6-inch (75 through 150 mm) diameter.
 - (viii) ASTM F892—Polyethylene (PE) Corrugated Pipe with a Smooth Interior and Fittings. This specification covers corrugated PE pipe 4 inches (100 mm) in diameter.
 - (ix) ASTM F894—Polyethylene (PE) Large Diameter Profile Wall Sewer and Drainpipe. The specification covers profile wall PE pipe from 18- to 120-inch (450 to 3,000 mm) diameter for low pressure and gravity flow applications.
- (3) Polyvinyl Chloride (PVC) Pipe
- (i) PVC pipe is used for gravity and low pressure flow systems. PVC composite pipe is a combination of a PVC pipe with a series of truss annuli. It is filled with lightweight portland cement concrete or other such material. PVC fittings are widely available. PVC pipe should be manufactured in accordance with one or more of the following standard specifications:
 - (ii) AASHTO M304—Poly (Vinyl Chloride) (PVC) Ribbed Drainpipe and Fittings Based on Controlled Inside Diameter. This specification covers 18- to 48-inch diameter ribbed PVC pipe.
 - (iii) ASTM D2680/AASHTO M264—Acrylonitrile-Butadiene-Styrene (ABS) and Poly (Vinyl Chloride) (PVC) Composite Sewer Piping. These specifications cover ABS or PVC composite pipe, fittings, and a joining system for storm drain systems in 6- through 15-inch (150 through 375 mm) diameter.
 - (iv) ASTM D2729—Poly (Vinyl Chloride) (PVC) Sewer Pipe and Fittings. This specification covers PVC pipe and fittings for sewer and drainpipe from 2-inch (50 mm) to 6-inch (150 mm) diameters.

- (v) ASTM D3034—Type PSM Poly (Vinyl Chloride) (PVC) Sewer Pipe and Fittings. This specification covers PVC pipe and fittings from 4- through 15-inch (100 to 375 mm) diameters.
 - (vi) ASTM F679—Poly (Vinyl Chloride) (PVC) Large Diameter Plastic Gravity Sewer Pipe and Fittings. This specification covers PVC gravity sewer pipe and fittings from 18- through 36-inch (450 through 900 mm) diameters with integral bell elastomeric seal joints and smooth inner walls.
 - (vii) ASTM F758—Smooth-Wall Poly (Vinyl Chloride) (PVC) Plastic Underdrain Systems for Highways, Airports, and Similar Drainage. This specification covers PVC pipe and fittings for underdrains from 4- through 8-inch (100 through 200 mm) diameters with perforated or nonperforated walls for use in subsurface drainage systems.
 - (viii) ASTM F789—Type PS-46 Poly (Vinyl Chloride) (PVC) Plastic Gravity Flow Sewer Pipe and Fittings. This specification covers requirements for PVC gravity sewer pipe and fittings from 4- through 18-inch (100 through 450 mm) diameters.
 - (ix) ASTM F794—Poly (Vinyl Chloride) (PVC) Profile Gravity Sewer Pipe and Fittings Based on Controlled Inside Diameter. This specification covers PVC pipe and fittings from 4 through 48 inches (200 through 1200 mm) with integral bell and elastomeric seal joints.
 - (x) ASTM F949—Poly (Vinyl Chloride) (PVC) Corrugated Sewer Pipe with a Smooth Interior and Fittings. This specification gives requirements for PVC pipe and fittings from 4- through 36-inch (100 through 900 mm) diameters with corrugated outer wall and smooth inner wall.
- (4) Acrylonitrile-butadiene-styrene (ABS) pipe and ABS composite pipe
- (i) ABS and ABS composite pipe should be manufactured in accordance with one of the following standard specifications:
 - (ii) ASTM D2680/AASHTO M264—Acrylonitrile-Butadiene-Styrene (ABS) and Poly (Vinyl Chloride) (PVC) Composite Sewer Piping. These specifications cover ABS or PVC composite pipe, fittings, and a joining system for 4- to 15-inch (100 to 375 mm) diameter.
 - (iii) ASTM D2751—Acrylonitrile-Butadiene-Styrene (ABS) Sewer Pipe and Fittings. This specification covers ABS pipe and fittings from 3- through 12-inch (75 through 300 mm) diameter.
- (5) Metal Pipe
- (i) Corrugated metal pipe is fabricated from corrugated steel or aluminum sheets or coils. Corrugated metal pipe is specified by size, shape, wall profile, gauge or wall thickness, and coating or lining. Appurtenances including tees, wyes, elbows, and manholes are available. Corrugated metal pipe should be manufactured in accordance with one or more of the following standard specifications:
 - (ii) AASHTO M190—Bituminous Coated Corrugated Metal Culvert Pipe. This specification covers characteristics of bituminous coated corrugated metal and pipe arches meeting AASHTO M36.
 - (iii) ASTM A760/AASHTO M36—Corrugated Steel Pipe, Metallic-Coated for Sewers and Drains. These specifications cover metallic-coated corrugated steel pipe from 4- through 144-inch (100 to 3600 mm) diameter.
 - (iv) ASTM A762/AASHTO M245—Corrugated Steel Pipe, Polymer Precoated for Sewers and Drains. These specifications cover polymer precoated corrugated steel pipe from 4- through 144-inch (100 through 3600 mm) diameter.

- (v) ASTM B745/AASHTO M196—Corrugated Aluminum Pipe for Sewers and Drains. These specifications cover corrugated aluminum pipe from 4- through 144-inch (100 through 3600 mm) diameter.
- (6) Vitrified Clay Pipe (VCP)
 - (i) VCP is manufactured from clays and shales and vitrified at high temperatures. VCP is available in several strength classifications, and is specified by nominal pipe diameter, strength and type of joint. The product should be manufactured in accordance with one or more of the following standard specifications:
 - (ii) ASTM C4/AASHTO M179—Clay Drain Tile. These specifications cover drain tile from 4- through 30-inch (100 through 750 mm) diameter in standard, extra quality, and heavy-duty strengths.
 - (iii) ASTM C498—Clay Drain Tile, Perforated. This specification covers perforated drain tile from 4- through 18-inch (100 through 450 mm) diameters in standard, extra quality, heavy duty, and extra strength.
 - (iv) ASTM C700/M65—Vitrified Clay Pipe, Extra Strength, Standard Strength, and Perforated. These specifications cover perforated and nonperforated pipe from 3- through 42-inch (75 through 1,050 mm) diameters in extra strength and standard strength.
- (7) Other Materials and Products

Geocomposites, geomembranes, geotextiles, aggregates, wick drains, and pump and lift stations may not be covered by conservation practice standards. The requirements for such materials and products must be specified in construction contract documents by an engineer. Contact individual manufacturers for more detail on specific products.

650.1414 Appurtenances

A. Surface Inlets

Surface inlets should be used in low areas where surface drainage otherwise cannot be provided. They must be properly constructed to prevent washouts and silting of the line. Surface inlets should be avoided wherever possible. If silt is a hazard, place a silt trap (fig. 14-53) at a convenient location immediately downstream from the inlet or use a blind inlet (fig. 14-54). Blind inlets allow entry of surface water from small ponded areas into the drain without an open riser. The sand-gravel material for the porous medium must be appropriately designed to keep out sediment and prevent piping of base soil material yet provide free water movement into the drain.

Figure 14-53: Junction Box and Silt Trap






Figure 14-54: Blind Surface Inlet Elevation



Cross-Section




B. Junction Boxes

Junction boxes should be used where two or more main or submain drains join or where several laterals join at different elevations. If the junction is in a cultivated field, the box should be constructed so that the top is at least 18 inches below the surface of the ground. It can be capped and covered, and its position referenced for future relocation (fig. 14-53).

C. Vents and Relief Wells

Vents, or breathers, are used to alleviate vacuum or negative pressure in the line. Breathers should be used where the line changes abruptly from a flat section to a steep section. Permanent fence crossings are good locations for installation. Relief wells relieve pressure in the line. They should be installed where steep sections change to flat sections unless the flatter section has about 25 percent greater capacity than the steeper section. They should be used on lines that have surface inlets, particularly when such inlets are large (fig. 14-55).


Figure 14-55: Vents or Relief Wells



D. Outlet Protection


- (1) Where drains outlet into an open ditch, the end of the drainage line should be protected. If surface water enters the outlet at the same location as the drain, some type of structure, such as a headwall or earth berm, is needed over the outlet. Where there is no surface water, the most practical and economical outlet is a section of rigid pipe. The pipe should conform to the requirements shown in figure 14-56.

Figure 14-56: Pipe Outlet



- (2) Where burning to control weeds may occur, the pipe should be fireproof. A swing gate or some type of grating or coarse screen should be used on all outlets to exclude rodents and other small animals (fig. 14-57). The screen mesh should not be less than 1 inch. Swing gates, rather than fixed screens or grates, should be used where surface water enters a system directly.

Figure 14-57: Outlet Pipe Protection



650.1415 Drain Installation

A. Inspection of Materials

All materials of a subsurface drainage system should be inspected before the system is installed. Materials should be satisfactory for the intended use and should meet standards and specifications. Any defective or damaged clay or concrete drain tile should be rejected, and defective or damaged sections of plastic tubing should be removed. The perforations in the plastic tubing must be the proper size. Check pipe for the specification to which it is manufactured (ASTM, AASHTO) as well as NRCS Practice Standard.

B. Storage of Materials

Drainage materials should be protected from damage during handling and storage. More precautions should be taken to protect plastic tubing. End caps can be used if rodents are a problem. Tubing that has filter wrap should be covered. Because tubing can be harmed by excessive exposure to ultraviolet rays, it must be protected from long exposures to sunlight. Coils of tubing should be stacked no more than four high, and reels should not be stacked.

C. Staking

Presently, field staking is at a minimum because most installations are done with laser controlled equipment (fig. 14-58).

Figure 14-58: Laser Grade Control



D. Utilities

- (1) Special caution must be taken when trench or trenchless work is performed because of the danger if utilities are too near. Many jurisdictions have systems in place that require notification and location of utility lines before any excavations. Most require advance notification when excavation is to take place and have special telephone numbers for notification. Some states and metropolitan areas use a single telephone contact to alert local utility companies of pending construction activities (ASCE 1993).

- (2) Utilities should be located when preparing plans, and procedures are needed to assure contractors have noted the utilities and have taken the necessary precautions. The location of all underground utilities and structures should be indicated on construction plans or drawings. Safety is the primary concern, but interruption of services can create tremendous economic problems. Whether underground utilities are shown on the plans or not, the contractor is required by OSHA and possibly local or state law to contact local utility companies to ascertain if there is a potential for involvement.

E. Crossing Waterways and Roads

Special precautions should be taken where drains are placed under waterways or roads. Figure 14-59 provides some guidance for these crossings, but, if exceptionally heavy trucks and equipment are expected, an engineer should be consulted.

Figure 14-59: Drain Crossings and Outlets






Figure 14-59: Drain Crossings and Outlets - continued
Methods for handling shallow depths at drain outlet



F. Shaping the Trench Bottom

- (1) The bottom of the drain trench should be shaped so that a fourth or more of the drain's circumference is on solid ground. Trenching machines shape the trench properly as a part of the trenching operation. Backhoe buckets can also be modified to provide a proper shape. Where drains are laid through unstable pockets of soil, one of the following materials should be placed in the bottom of the trench to support the drain:
 - (i) stable soil
 - (ii) crushed rock
 - (iii) sand/gravel bedding
- (2) For corrugated plastic pipe, a specially shaped groove must be made in the trench bottom if the design does not call for a gravel envelope. The groove shape can be a semicircle, trapezoid, or a 90-degree V. A 90-degree V-groove of sufficient depth is recommended for 3- to 6-inch pipe; however, if the pipe is installed on a steep grade, the bottom of the trench should be shaped to fit the pipe closely (fig. 14-60).

Figure 14-60: Dimensions for a 90 Degree V Groove for Corrugated Plastic Pipe

G. Laying Corrugated Plastic Pipe (CPP)

Trenching machines or drainage plows are used to install most CPP. Any stretch that occurs during installation decreases the pipe strength somewhat and may pull perforations open wider than is desirable. The amount of stretch that occurs during installation depends on the temperature of the CPP at the time it is installed, the amount and duration of drag that occurs when the CPP is fed through the installation equipment, and the stretch resistance of the pipe. The use of a power feeder is recommended for all sizes of CPP. Stretch, which is expressed as a percentage of length, should not exceed 5 percent.

H. Drain Envelope Installation.

(1) Drain Filter Envelopes

- (i) The best quality filter envelope material cannot compensate for improper installation, especially in fine, weakly structured soils that are saturated. Reliable drain envelope material will only be successful if installed under favorable physical soil conditions. General excess wetness of a soil may adversely affect structural stability, hence the soil manipulation caused by the trenching operation while installing drains may destroy the soil structure. This leads to soil slaking, enhanced risk of mineral clogging of filter envelopes and pipes, and a low hydraulic conductivity of the soil itself. Gravel filter envelopes tend to be less susceptible to poor installation conditions, but they can also fail because of adverse conditions at the time of installation. Geotextile filter envelopes are normally prewrapped and have sufficient mechanical strength to withstand the mechanical stresses of installation. Because of this, attention should be primarily on preserving the hydraulic function.
- (ii) The ideal condition for installation of subsurface drains is to place the drains in an unsaturated soil. If the soil has a high-water table that cannot be lowered before installation, every effort should be made to preserve the existing soil structure and to protect the drain from trench wall failure. Adjusting the forward speed of the installation machine may help to limit the destruction of soil structure. If the condition of the excavated material is observed, it can be a guide to the proper machine speed. The machine should move fast enough to preserve the structure of the soil and not turn the excavated soil into a slurry. Simultaneous and instantaneous backfilling can prevent trench wall failure.

- (iii) Drain plows have been developed that install drains with synthetic and gravel drain envelopes. Plowed in (trenchless) drains avoid many of the problems of trenched or backhoe excavated drain installation. Unfortunately, they present their own unique set of problems. They are limited to shallow depths and small pipe sizes and may produce compaction around the drain under certain soil texture and moisture conditions. Moreover, rocky soils can be a problem for this equipment.
- (2) Sand-Gravel Drain Envelopes
- (i) Most of the water entering a subsurface drain moves through openings in the sides and bottom of the drain, below the hydraulic gradeline inside the drain. The hydraulic gradients that develop at the drain openings are often high enough to cause an unstable condition at the opening, and consequently piping of the soil material may occur. The noncohesiveness of many soils makes them particularly susceptible to movement when saturated. For these reasons, an adequate amount of filter envelope material is needed around the drainpipe.
 - (ii) Where drains are laid by hand, a layer of drain envelope material is placed in the bottom of the trench and is leveled to the design grade before the drain is laid. The drainpipe is then put into place and covered with envelope material to the required depth. The trench is then backfilled with soil. Some trenching machines are fitted with two hoppers for placing drain envelope material under and over a drain on a continuous basis. One hopper near the digging device covers the trench bottom with the required thickness of drain envelope material. The pipe is placed and the second hopper at the rear of the trenching machine covers the pipe with drain envelope material.
 - (iii) In a common variation of the two-hopper design, the pipe is guided through an enclosed single gravel hopper chute and emerges at the rear of the shield along with the gravel. In either case, the shield design is critical. If gravel segregation occurs within the shield, an improper gradation results and often leads to drain failure. Also, the design must be such that the pipe is not subject to tension caused by friction between the gravel and the shield walls. Such tension results in stretching the pipe beyond acceptable limits.
 - (iv) Drainage contractors have recently developed procedures for placing drain envelope material completely around a drainpipe in one operation using a single hopper. Single hopper placement is used for both rigid and flexible pipes. The pipe within the machine is suspended above the bottom of the trench so the granular envelope material can flow around the pipe. This single stage placement has resulted in material economies since it is possible to make an approximately concentric drain envelope by preshaping the trench bottom. Drain plows that install flexible corrugated plastic drainpipes with drain envelopes have uniformly concentric envelope placement.
 - (v) In unstable soil the drainpipe and drain envelope are sometimes displaced by soil movement before and during backfilling. The sides of the open trench may fall or slough causing lateral misalignment of the pipes. If the soil around or in the bottom of the trench is saturated and unstable, it may move upward as a fluid displacing the envelope material and pushing the pipe out of line. Simultaneous backfilling is particularly desirable in unstable soil conditions. Movement of saturated unstable soil may also cause puddling of the backfill material and plugging of the filter envelope, or any drain envelope material, during construction. A slurry in the bottom of a trench generally causes immediate and complete failure of synthetic drain envelope material.

- (vi) Protection of the drain envelope and drain system immediately following installation is important. No heavy loads, mechanical or hydraulic, should be imposed until the soil in the trench is consolidated. The loose backfill material will settle naturally with time. Passage of a lightweight vehicle wheel in the trench speeds up the process, but care must be taken to avoid crushing the drainpipe.
 - (vii) Application of irrigation water to unconsolidated material in the trenches to settle the backfill is a practice that should be done carefully. Muddy water moving through the porous backfill material directly into the filter envelope under high hydraulic heads can cause plugging of the filter envelope material at the drain openings. Such plugging reduces the effectiveness of the drain envelope. It may also result in sedimentation in the drain or even complete plugging of the filter envelope.
- (3) Envelope Thickness
- (i) One of the benefits of drain envelope placement is the increase in permeability along the pipe that enables water to flow more freely to the open joints or perforations. The effect is similar to converting the pipe from one with limited openings to one that is completely permeable. This increased permeability can probably be obtained with an envelope 0.5 inches thick. Theoretically, corrugated pipes should be perforated in every corrugation to reduce secondary convergence at the openings.
 - (ii) Increasing the diameter of the drain envelope effectively reduces the waterflow velocity and exit gradient at the soil and envelope interface (Willardson and Walker 1979), thereby decreasing the probability of soil particle movement. If the permeable hydraulic envelope material is considered to be an extension of the pipe diameter, then the thicker the envelope the better. Some practical limitations to increasing drain envelope thickness include:
 - The perimeter of the envelope through which flow occurs increases as the first power of the diameter of the envelope, while the amount of envelope material required increases as the square of the diameter.
 - Doubling the diameter of the envelope and consequently decreasing the inflow velocity at the soil and envelope interface by half would require four times the volume of envelope material.
 - (iii) Corrugated plastic drainpipes with close perforation spacing reduce the requirement for a hydraulic envelope material to transport water to widely spaced openings that were common where 1- to 3-foot lengths of rigid pipe were used for drainage. The practical problems of placement probably dictates a design minimum sand-gravel drain envelope thickness of approximately 3 inches. The principal reason for a thicker envelope in a problem soil would be to reduce the exit gradient to a value below the hydraulic failure gradient of the soil and to nullify the effects of construction inconsistencies. Figure 14-59 illustrates sand-gravel envelope placement recommendations.

I. Alignment and Joints.

(1) Plastic Pipe

Manufactured couplers should be used at all joints and fittings of corrugated plastic pipe, at all changes in direction where the centerline radius is less than three times the pipe diameter, at changes in diameter, and at the end of the line. All connections must be compatible with the pipe. Where certain fittings are not available, hand-cut connections are acceptable if they are reinforced with a cement mortar or other material that makes a strong, tight joint. The connection should not create a means of obstructing flow, catching debris inside the conduit, or allowing soil to enter the line.

(2) Tile

- (i) Alignment in main and lateral drains should generally be straight, and junction boxes should be used to affect changes in direction. Y and T joints can be used. Manufactured connections are preferred, but chipped or fitted connections that are sealed may be installed if manufactured connections are not available.
- (ii) Laterals should be connected to mains so that their centerlines meet. Any curves in mains and laterals should have a radius of more than 50 feet. If gaps in excess of 1/4 inch in clay soils or 1/8 inch in sandy soils occur in the outer side of a curved line, they should be covered with an impermeable material.
- (iii) Joints between tile laid in straight or nearly straight lines should be about 1/8-inch-wide unless the soil is sandy. Tile laid in sandy soil should be butted together. If gaps exceed 1/4 inch in clay soils or 1/8 inch in sand, they should be covered with broken tile batts or wrapped with impermeable material. In certain soils where experience shows that tile lines fill with sediment within a few years, joints should be protected by wrapping or covering.

J. Safety and Protection During Construction

- (1) At the end of each day's work, the end of the drain being placed should be completely closed to prevent small animals or, in the event of rain, silt and debris from entering the line. A wooden or metal plate or some other device can be used. Upon completion of the line, the upper end of the drain should be closed tightly using a plate, end cap, or some other permanent material.
- (2) Contractors are responsible for construction site safety. Federal regulations covering safety for all types of construction are published in the Safety and Health Regulations for Construction under the Department of Labor, Occupational Safety and Health Administration (OSHA). Many states, municipalities, and other local agencies have established codes and safety practices regarding construction. These regulations apply to subsurface drainage installation as well as all types of construction, including alteration and repair work. Personnel and contractors associated with drainage installation should be thoroughly familiar with the safety requirements and follow the required practices, procedures, and standards.

K. Blinding and Backfill

- (1) As soon as the drains are placed, they should be blinded by covering them with soil to a depth of 6 to 12 inches. They should not be left exposed overnight because damage can occur from rain and trench caving. Loose topsoil, either taken from the sides of the trench or excavated during trenching operations, provides good blinding material.

- (2) Backfilling of the trench should be done as soon after blinding as possible to prevent damage from surface water. This generally is done by mechanical means. Some trenchers have backfilling attachments that place the excavated material in the trench as the drain is laid.

L. Protection for Biological and Mineral Clogging

- (1) The following installation procedures may minimize ochre problems for shallow drains in humid areas.
- (2) In ochreous areas, drains should not be installed below the water table. If possible, drains should be installed during the dry season when the water table is low because the iron in the soil will be in the insoluble form and stabilization of the drain and surrounding soil will help to minimize the possibility of ochre becoming a serious problem.
- (3) Drains should open into ditches, rather than through collector systems. If a small area in a field is ochreous, the trouble could be confined to a single drain. Cleaning is also easier for single drains.
- (4) Clogging is more severe shortly after drain installation. The best cleaning method is to jet the drains during the first year after installation rather than wait until the drains are clogged. One method of cleaning has vents at the upper end of the lines that are used as ports to pour large quantities of water into the drains for flushing action. This method will not clean the valleys of the corrugations.
- (5) Shallow drains and closely spaced drains that flow infrequently are not as troublesome, even though the site may be rated serious for ochre potential.
- (6) Drains in marl soils generally have fewer problems, unless the drains are installed deep in the soil profile.
- (7) Avoid blinding the drain with topsoil or organic materials.

M. Checking

The most practical way to check the drain installation is after the drain has been laid and before the trench is backfilled; however, checking can be done using a probe after backfilling.

N. As-built Plans

As-built or record drawings are recommended for future reference. They can be done by GPS mapping process, aerial photography, or traditional survey methods.

650.1416 Maintenance

A. Maintenance of subsurface drains is needed throughout the drain's expected useful life. Outlets should be inspected regularly. If they are not fire-resistant or fire-proof, they need to be protected from weed burning operations. Corrugated plastic tubing is not suitable for the outlet section. Maintenance problems are reduced if the outlet is a short section of solid pipe. The gates or screens of outlets must be checked to assure that entry of rodents and other small animals is restricted and that they are free of sediment build-up, weeds, debris, and seasonal ice blockage.

B. General observation of the entire subsurface drainage system will reveal areas of possible failure. Sinkholes or cave-ins over the drains indicate that soil piping problems have occurred. The problem may be a broken or collapsed drainage conduit or an opening in the filter or envelope material that allows soil material to enter the drain. Following the spring drying period, puddles or wet areas can indicate a plugged line or filter fabric or areas where additional drains are needed.

C. Jet Cleaning

- (1) High pressure jet cleaning has been successfully used for removal of ochre, silt, and roots from subsurface drains (fig. 14-61). This practice has been used extensively in Northern Europe and in the U.S.
- (2) Timely maintenance of subsurface drainage systems in areas of ochre development is critical. Subsurface drains should not be installed in sites having permanent ochre potential unless some provision is made for frequent jet cleaning.
- (3) Temporary ochre as a clogging factor may diminish or disappear over a period of 3 to 8 years if drains are maintained in a free-flowing condition. It generally occurs rapidly and often can be detected at drain outlets within the first few months after drain installation. If drains can be maintained in working order, ferrous iron reaching them may diminish over a period of time.
- (4) Permanent ochre is the most serious problem because it continues to be a clogging agent for the life of the drainage system, regardless of treatment. The use of high and low pressure water jetting has been successful in cleaning many drains clogged with ochre. Nozzle pressure should not exceed 400 psi in sandy soils; otherwise sand around the drains may become unstable and flow into the drain. Jetting nozzles designed for agricultural drains should be used rather than those designed for cleaning municipal sewer lines. Jet cleaning should not be delayed until the ochre has aged and become crystalline.

Figure 14-61: High Pressure Jet Cleaning



D. Acid Solutions

A second method for cleaning drains involves an acid solution to dissolve the iron. This method cannot be used with synthetic envelopes, and the outflow after treatment may need to be neutralized to prevent pollution downstream. Some acids, especially sulfuric, may damage concrete lines.